# SUN5000-(150K-MG0-ZH,150K-MG0)

# **User Manual**

**Issue** 01

**Date** 2024-03-20





#### Copyright © Huawei Technologies Co., Ltd. 2024. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd.

#### **Trademarks and Permissions**

HUAWEI and other Huawei trademarks are trademarks of Huawei Technologies Co., Ltd. All other trademarks and trade names mentioned in this document are the property of their respective holders.

#### **Notice**

The purchased products, services and features are stipulated by the contract made between Huawei and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

# Huawei Technologies Co., Ltd.

Address: Huawei Industrial Base

Bantian, Longgang Shenzhen 518129

People's Republic of China

Website: <a href="https://e.huawei.com">https://e.huawei.com</a>

# **About This Document**

## **Purpose**

This document describes the following inverter models (also referred to as SUN5000) in terms of the safety precautions, product introduction, installation, electrical connections, power-on and commissioning, maintenance, and technical specifications. Read this document carefully before installing and operating the inverter.

- SUN5000-150K-MG0-ZH
- SUN5000-150K-MG0

## **Intended Audience**

This document is intended for:

- Technical support engineers
- Hardware installation engineers
- Commissioning engineers
- Maintenance engineers

# **Symbol Conventions**

The symbols that may be found in this document are defined as follows.

Symbol	Description		
Indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.			
<b>⚠ WARNING</b>	Indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.		
⚠ CAUTION Indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.			

Symbol	Description
ΝΟΤΙCΕ	Indicates a potentially hazardous situation which, if not avoided, could result in equipment damage, data loss, performance deterioration, or unanticipated results.  NOTICE is used to address practices not related to personal injury.
☐ NOTE	Supplements the important information in the main text.  NOTE is used to address information not related to personal injury, equipment damage, and environment deterioration.

# Issue 01 (2023-03-20)

This issue is used for first office application (FOA).

# **Contents**

About This Document	i
1 Safety Information	1
1.1 Personal Safety	2
1.2 Electrical Safety	4
1.3 Environment Requirements	7
1.4 Mechanical Safety	
2 Overview	13
2.1 Model	13
2.2 Networking Application	14
2.2.1 Typical Networking	14
2.2.2 Earthing Systems	18
2.3 Appearance	
2.4 Circuit Diagram	
2.5 Working Modes	
2.6 Label Description	24
3 Storage Requirements	27
4 Installation	29
4.1 Installation Modes	29
4.2 Installation Requirements	29
4.2.1 Site Selection Requirements	30
4.2.2 Clearance Requirements	32
4.2.3 Angle Requirements	
4.3 Preparing Tools	35
4.4 Checking Before Installation	
4.5 Moving the Inverter	
4.6 Installing the Inverter on a Support	
4.7 Installing the Inverter on a Wall	
4.8 Installing the Inverter on a Pole Clamp	42
5 Electrical Connections	43
5.1 Precautions	43
5.2 Preparing Cables	44

5.3 Connecting a PE Cable	48
5.4 Connecting an AC Output Power Cable	
5.5 Connecting DC Input Power Cables	
5.5.1 Measuring the Insulation Resistance of PV Strings to the Ground	
5.5.2 Connecting DC Input Power Cables	
5.6 Connecting Signal Cables	62
5.7 (Optional) Installing the Smart Dongle	64
6 Checking Before Power-On	67
7 Power-On and Commissioning	68
7.1 Powering On the Inverter	
7.2 Commissioning Methods and Process	74
7.3 Commissioning the SUN5000 (Using the SmartLogger)	76
7.3.1 Preparations and SmartLogger WebUI Login	76
7.3.2 Software Upgrade	76
7.3.3 Commissioning Using the Deployment Wizard	77
7.3.4 Parameters Settings	80
7.4 Commissioning the SUN5000 (Using the App)	80
7.4.1 Downloading the FusionSolar App	80
7.4.2 Registering an Installer Account	
7.4.3 Deploying a New Plant	81
8 System Maintenance	82
8.1 Routine Maintenance	82
8.2 Shutdown and Power-Off	84
8.3 Power-Off for Maintenance	85
8.4 Replacing a Fan	86
8.5 Resetting and Turning On the DC Switch	
8.6 Locating Insulation Resistance Faults	
9 Alarm Reference	94
10 Technical Specifications	95
A Grid Codes	99
B Rapid Shutdown	114
C Resetting a Password	115
D Crimping an OT or DT Terminal	116
E Baud Rate Negotiation	119
F Contact Information	121
G Digital Power Customer Service	123
H Acronyms and Abbreviations	124

# **1** Safety Information

#### Statement

Before transporting, storing, installing, operating, using, and/or maintaining the equipment, read this document, strictly follow the instructions provided herein, and follow all the safety instructions on the equipment and in this document. In this document, "equipment" refers to the products, software, components, spare parts, and/or services related to this document; "the Company" refers to the manufacturer (producer), seller, and/or service provider of the equipment; "you" refers to the entity that transports, stores, installs, operates, uses, and/or maintains the equipment.

The Danger, Warning, Caution, and Notice statements described in this document do not cover all the safety precautions. You also need to comply with relevant international, national, or regional standards and industry practices. The Company shall not be liable for any consequences that may arise due to violations of safety requirements or safety standards concerning the design, production, and usage of the equipment.

The equipment shall be used in an environment that meets the design specifications. Otherwise, the equipment may be faulty, malfunctioning, or damaged, which is not covered under the warranty. The Company shall not be liable for any property loss, personal injury, or even death caused thereby.

Comply with applicable laws, regulations, standards, and specifications during transportation, storage, installation, operation, use, and maintenance.

Do not perform reverse engineering, decompilation, disassembly, adaptation, implantation, or other derivative operations on the equipment software. Do not study the internal implementation logic of the equipment, obtain the source code of the equipment software, violate intellectual property rights, or disclose any of the performance test results of the equipment software.

# The Company shall not be liable for any of the following circumstances or their consequences:

- The equipment is damaged due to force majeure such as earthquakes, floods, volcanic eruptions, debris flows, lightning strikes, fires, wars, armed conflicts, typhoons, hurricanes, tornadoes, and other extreme weather conditions.
- The equipment is operated beyond the conditions specified in this document.

- The equipment is installed or used in environments that do not comply with international, national, or regional standards.
- The equipment is installed or used by unqualified personnel.
- You fail to follow the operation instructions and safety precautions on the product and in the document.
- You remove or modify the product or modify the software code without authorization.
- You or a third party authorized by you cause the equipment damage during transportation.
- The equipment is damaged due to storage conditions that do not meet the requirements specified in the product document.
- You fail to prepare materials and tools that comply with local laws, regulations, and related standards.
- The equipment is damaged due to your or a third party's negligence, intentional breach, gross negligence, or improper operations, or other reasons not related to the Company.

## 1.1 Personal Safety

#### **⚠** DANGER

Ensure that power is off during installation. Do not install or remove a cable with power on. Transient contact between the core of the cable and the conductor will generate electric arcs or sparks, which may cause a fire or personal injury.

#### **⚠** DANGER

Non-standard and improper operations on the energized equipment may cause fire, electric shocks, or explosion, resulting in property damage, personal injury, or even death.

#### **⚠** DANGER

Before operations, remove conductive objects such as watches, bracelets, bangles, rings, and necklaces to prevent electric shocks.


### **DANGER**

During operations, use dedicated insulated tools to prevent electric shocks or short circuits. The dielectric withstanding voltage level must comply with local laws, regulations, standards, and specifications.

## **MARNING**

During operations, wear personal protective equipment such as protective clothing, insulated shoes, goggles, safety helmets, and insulated gloves.

Figure 1-1 Personal protective equipment



## **General Requirements**

- Do not stop protective devices. Pay attention to the warnings, cautions, and related precautionary measures in this document and on the equipment.
- If there is a likelihood of personal injury or equipment damage during operations, immediately stop, report the case to the supervisor, and take feasible protective measures.
- Do not power on the equipment before it is installed or confirmed by professionals.
- Do not touch the power supply equipment directly or with conductors such as damp objects. Before touching any conductor surface or terminal, measure the voltage at the contact point to ensure that there is no risk of electric shock.
- Do not touch operating equipment because the enclosure is hot.
- Do not touch a running fan with your hands, components, screws, tools, or boards. Otherwise, personal injury or equipment damage may occur.
- In the case of a fire, immediately leave the building or the equipment area and activate the fire alarm or call emergency services. Do not enter the affected building or equipment area under any circumstances.

### **Personnel Requirements**

- Only professionals and trained personnel are allowed to operate the equipment.
  - Professionals: personnel who are familiar with the working principles and structure of the equipment, trained or experienced in equipment operations and are clear of the sources and degree of various potential hazards in equipment installation, operation, maintenance

- Trained personnel: personnel who are trained in technology and safety, have required experience, are aware of possible hazards on themselves in certain operations, and are able to take protective measures to minimize the hazards on themselves and other people
- Personnel who plan to install or maintain the equipment must receive adequate training, be able to correctly perform all operations, and understand all necessary safety precautions and local relevant standards.
- Only qualified professionals or trained personnel are allowed to install, operate, and maintain the equipment.
- Only qualified professionals are allowed to remove safety facilities and inspect the equipment.
- Personnel who will perform special tasks such as electrical operations, working at heights, and operations of special equipment must possess the required local qualifications.
- Only authorized professionals are allowed to replace the equipment or components (including software).
- Only personnel who need to work on the equipment are allowed to access the equipment.

# 1.2 Electrical Safety

## **A** DANGER

Before connecting cables, ensure that the equipment is intact. Otherwise, electric shocks or fire may occur.

### **DANGER**

Non-standard and improper operations may result in fire or electric shocks.

#### DANGER

Prevent foreign matter from entering the equipment during operations. Otherwise, equipment short-circuits or damage, load power derating, power failure, or personal injury may occur.

#### **№** WARNING

For the equipment that needs to be grounded, install the ground cable first when installing the equipment and remove the ground cable last when removing the equipment.

## **↑** WARNING


During the installation of PV strings and the inverter, the positive or negative terminals of PV strings may be short-circuited to ground if the power cables are not properly installed or routed. In this case, an AC or DC short circuit may occur and damage the inverter. The resulting device damage is not covered under any warranty.

## **⚠** CAUTION

Do not route cables near the air intake or exhaust vents of the equipment.

## **General Requirements**

- Follow the procedures described in the document for installation, operation, and maintenance. Do not reconstruct or alter the equipment, add components, or change the installation sequence without permission.
- Obtain approval from the national or local electric utility company before connecting the equipment to the grid.
- Observe the power plant safety regulations, such as the operation and work ticket mechanisms.
- Install temporary fences or warning ropes and hang "No Entry" signs around the operation area to keep unauthorized personnel away from the area.
- Before installing or removing power cables, turn off the switches of the equipment and its upstream and downstream switches.
- Before performing operations on the equipment, check that all tools meet the requirements and record the tools. After the operations are complete, collect all of the tools to prevent them from being left inside the equipment.
- Before installing power cables, check that cable labels are correct and cable terminals are insulated.
- When installing the equipment, use a torque tool of a proper measurement range to tighten the screws. When using a wrench to tighten the screws, ensure that the wrench does not tilt and the torque error does not exceed 10% of the specified value.
- Ensure that bolts are tightened with a torque tool and marked in red and blue after double-check. Installation personnel mark tightened bolts in blue.
   Quality inspection personnel confirm that the bolts are tightened and then mark them in red. (The marks must cross the edges of the bolts.)



- If the equipment has multiple inputs, disconnect all the inputs before operating the equipment.
- Before maintaining a downstream electrical or power distribution device, turn off the output switch on the power supply equipment.

- During equipment maintenance, attach "Do not switch on" labels near the
  upstream and downstream switches or circuit breakers as well as warning
  signs to prevent accidental connection. The equipment can be powered on
  only after troubleshooting is complete.
- Do not open equipment panels.
- Check equipment connections periodically, ensuring that all screws are securely tightened.
- Only qualified professionals can replace a damaged cable.
- Do not scrawl, damage, or block any labels or nameplates on the equipment. Promptly replace labels that have worn out.
- Do not use solvents such as water, alcohol, or oil to clean electrical components inside or outside of the equipment.

## Grounding

- Ensure that the grounding impedance of the equipment complies with local electrical standards.
- Ensure that the equipment is connected permanently to the protective ground. Before operating the equipment, check its electrical connection to ensure that it is reliably grounded.
- Do not work on the equipment in the absence of a properly installed ground conductor.
- Do not damage the ground conductor.

## **Cabling Requirements**

- When selecting, installing, and routing cables, follow local safety regulations and rules.
- When routing power cables, ensure that there is no coiling or twisting. Do not join or weld power cables. If necessary, use a longer cable.
- Ensure that all cables are properly connected and insulated, and meet specifications.
- Ensure that the slots and holes for routing cables are free from sharp edges, and that the positions where cables are routed through pipes or cable holes are equipped with cushion materials to prevent the cables from being damaged by sharp edges or burrs.
- Ensure that cables of the same type are bound together neatly and straight and that the cable sheath is intact. When routing cables of different types, ensure that they are away from each other without entanglement and overlapping.
- Secure buried cables using cable supports and cable clips. Ensure that the
  cables in the backfill area are in close contact with the ground to prevent
  cable deformation or damage during backfilling.
- If the external conditions (such as the cable layout or ambient temperature) change, verify the cable usage in accordance with the IEC-60364-5-52 or local laws and regulations. For example, check that the current-carrying capacity meets requirements.
- When routing cables, reserve at least 30 mm clearance between the cables and heat-generating components or areas. This prevents deterioration or damage to the cable insulation layer.

## 1.3 Environment Requirements

## **A** DANGER

Do not expose the equipment to flammable or explosive gas or smoke. Do not perform any operation on the equipment in such environments.

## **DANGER**

Do not store any flammable or explosive materials in the equipment area.

#### **A** DANGER

Do not place the equipment near heat sources or fire sources, such as smoke, candles, heaters, or other heating devices. Overheat may damage the equipment or cause a fire.

## **MARNING**

Install the equipment in an area far away from liquids. Do not install it under areas prone to condensation, such as under water pipes and air exhaust vents, or areas prone to water leakage, such as air conditioner vents, ventilation vents, or feeder windows of the equipment room. Ensure that no liquid enters the equipment to prevent faults or short circuits.

## **MARNING**

To prevent damage or fire due to high temperature, ensure that the ventilation vents or heat dissipation systems are not obstructed or covered by other objects while the equipment is running.

## **General Requirements**

- Store the equipment according to the storage requirements. Equipment damage caused by unqualified storage conditions is not covered under the warranty.
- Keep the installation and operating environments of the equipment within the allowed ranges. Otherwise, its performance and safety will be compromised.
- The operating temperature range provided in the equipment's technical specifications refers to the ambient temperatures in equipment's installation environment.

- Do not install, use, or operate outdoor equipment and cables (including but not limited to moving equipment, operating equipment and cables, inserting connectors to or removing connectors from signal ports connected to outdoor facilities, working at heights, performing outdoor installation, and opening doors) in harsh weather conditions such as lightning, rain, snow, and level 6 or stronger wind.
- Do not install the equipment in an environment with dust, smoke, volatile or corrosive gases, infrared and other radiations, organic solvents, or salty air.
- Do not install the equipment in an environment with conductive metal or magnetic dust.
- Do not install the equipment in an area conducive to the growth of microorganisms such as fungus or mildew.
- Do not install the equipment in an area with strong vibration, noise, or electromagnetic interference.
- Ensure that the site complies with local laws, regulations, and related standards.
- Ensure that the ground in the installation environment is solid, free from spongy or soft soil, and not prone to subsidence. The site must not be located in a low-lying land prone to water or snow accumulation, and the horizontal level of the site must be above the highest water level of that area in history.
- Do not install the equipment in a position that may be submerged in water.
- If the equipment is installed in a place with abundant vegetation, in addition to routine weeding, harden the ground underneath the equipment using cement or gravel (the area shall be greater than or equal to 3 m x 2.5 m).
- Do not install the equipment outdoors in salt-affected areas because it may be corroded. A salt-affected area refers to the region within 500 m of the coast or prone to sea breeze. Regions prone to sea breeze vary with weather conditions (such as typhoons and monsoons) or terrains (such as dams and hills).
- Before installation, operation, and maintenance, clean up any water, ice, snow, or other foreign objects on the top of the equipment.
- When installing the equipment, ensure that the installation surface is solid enough to bear the weight of the equipment.
- After installing the equipment, remove the packing materials such as cartons, foam, plastics, and cable ties from the equipment area.

## 1.4 Mechanical Safety

## **⚠** WARNING

Ensure that all necessary tools are ready and inspected by a professional organization. Do not use tools that have signs of scratches or fail to pass the inspection or whose inspection validity period has expired. Ensure that the tools are secure and not overloaded.

## **MARNING**

Do not drill holes into the equipment. Doing so may affect the sealing performance and electromagnetic containment of the equipment and damage components or cables inside. Metal shavings from drilling may short-circuit boards inside the equipment.

## **General Requirements**

- Repaint any paint scratches caused during equipment transportation or installation in a timely manner. Equipment with scratches must not be exposed for an extended period of time.
- Do not perform operations such as arc welding and cutting on the equipment without evaluation by the Company.
- Do not install other devices on the top of the equipment without evaluation by the Company.
- When performing operations over the top of the equipment, take measures to protect the equipment against damage.
- Use correct tools and operate them in the correct way.

## **Moving Heavy Objects**

Be cautious to prevent injury when moving heavy objects.



< 18 kg (< 40 lbs)



18-32 kg (40-70 lbs)



32-55 kg (70-121 lbs)



55-68 kg (121-150 lbs)



(> 150 lbs) CZ0000110

- If multiple persons need to move a heavy object together, determine the manpower and work division with consideration of height and other conditions to ensure that the weight is equally distributed.
- If two persons or more move a heavy object together, ensure that the object is lifted and landed simultaneously and moved at a uniform pace under the supervision of one person.
- Wear personal protective gears such as protective gloves and shoes when manually moving the equipment.
- To move an object by hand, approach to the object, squat down, and then lift the object gently and stably by the force of the legs instead of your back. Do not lift it suddenly or turn your body around.
- Do not quickly lift a heavy object above your waist. Place the object on a workbench that is half-waist high or any other appropriate place, adjust the positions of your palms, and then lift it.
- Move a heavy object stably with balanced force at an even and low speed. Put
  down the object stably and slowly to prevent any collision or drop from
  scratching the surface of the equipment or damaging the components and
  cables.


- When moving a heavy object, be aware of the workbench, slope, staircase, and slippery places. When moving a heavy object through a door, ensure that the door is wide enough to move the object and avoid bumping or injury.
- When transferring a heavy object, move your feet instead of turning your waist around. When lifting and transferring a heavy object, ensure that your feet point to the target direction of movement.
- When transporting the equipment using a pallet truck or forklift, ensure that
  the tynes are properly positioned so that the equipment does not topple.
  Before moving the equipment, secure it to the pallet truck or forklift using
  ropes. When moving the equipment, assign dedicated personnel to take care
  of it.
- Choose sea, roads in good conditions, or airplanes for transportation. Do not transport the equipment by railway. Avoid tilt or jolt during transportation.

## **Using Ladders**


- Use wooden or insulated ladders when you need to perform live-line working at heights.
- Platform ladders with protective rails are preferred. Single ladders are not recommended.
- Before using a ladder, check that it is intact and confirm its load bearing capacity. Do not overload it.
- Ensure that the ladder is securely positioned and held firm.



- When climbing up the ladder, keep your body stable and your center of gravity between the side rails, and do not overreach to the sides.
- When a step ladder is used, ensure that the pull ropes are secured.
- If a single ladder is used, the recommended angle for the ladder against the floor is 75 degrees, as shown in the following figure. A square can be used to measure the angle.




- If a single ladder is used, ensure that the wider end of the ladder is at the bottom, and take protective measures to prevent the ladder from sliding.
- If a single ladder is used, do not climb higher than the fourth rung of the ladder from the top.
- If you use a single ladder to climb up to a platform, ensure that the ladder is at least 1 m higher than the platform.



## Hoisting

- Only trained and qualified personnel are allowed to perform hoisting operations.
- Install temporary warning signs or fences to isolate the hoisting area.
- Ensure that the foundation where hoisting is performed on meets the load-bearing requirements.
- Before hoisting objects, ensure that hoisting tools are firmly secured onto a fixed object or wall that meets the load-bearing requirements.
- During hoisting, do not stand or walk under the crane or the hoisted objects.
- Do not drag steel ropes and hoisting tools or bump the hoisted objects against hard objects during hoisting.
- Ensure that the angle between two hoisting ropes is no more than 90 degrees, as shown in the following figure.



## **Drilling Holes**

- Obtain consent from the customer and contractor before drilling holes.
- Wear protective equipment such as safety goggles and protective gloves when drilling holes.
- To avoid short circuits or other risks, do not drill holes into buried pipes or cables.
- When drilling holes, protect the equipment from shavings. After drilling, clean up any shavings.

# 2 Overview

The SUN5000 is a three-phase grid-tied PV string inverter that converts the DC power generated by PV strings into AC power and feeds the power into the power grid.


The SUN5000-150K-MG0 is intended to be used with a dedicated isolation transformer, through which the grid is connected.

## 2.1 Model

This document involves the following product models:

- SUN5000-150K-MG0-ZH
- SUN5000-150K-MG0

Figure 2-1 Model number



**Table 2-1** Model description

No.	Meaning	Description	
1	Product family identifier	SUN5000: grid-tied solar inverter that works with optimizers	
2	Power level identifier	150K: a rated power of 150 kW	
3	Product series identifier	MG0: product series with an input voltage level of 1100 V DC	
4	Region identifier	ZH: China	

# 2.2 Networking Application

## 2.2.1 Typical Networking

The SUN5000 supports RS485 and AC MBUS communication modes.

#### **NOTICE**

- The SUN5000 must work with MERC-(1300W, 1100W)-P optimizers.
- For the SUN5000-150K-MG0-ZH, the AC MBUS communication applies only to medium-voltage grid connection scenarios and non-low-voltage public grid connection scenarios (industrial environment).
- The SUN5000-150K-MG0 is intended to be used with a dedicated isolation transformer, through which the grid is connected.

#### □ NOTE

In the networking diagrams, — indicates the power cable, — indicates the power flow direction, and — indicate the signal flow.

## **RS485 Networking**

- Each COM port of the SmartLogger can connect to a maximum of 30 inverters and 1500 optimizers. A maximum of 80 inverters can be cascaded to each SmartLogger.
- The length of the RS485 cable between the inverter at the end and the SmartLogger cannot exceed 1000 m.
- A maximum of 240 optimizers can be connected to an inverter. The length of the cable between the optimizer at the end and the inverter cannot exceed 350 m.




Figure 2-2 RS485 networking application (SmartLogger)

- A maximum of 10 inverters can be cascaded to a Dongle.
- In the networking shown in Figure 2-3, if the number of optimizers is less than or equal to 1000, the total length of RS485 cables between inverters shall be less than or equal to 1000 m. In the networking shown in Figure 2-3, if the number of optimizers is greater than 1000 but less than or equal to 2400, the total length of RS485 cables between inverters shall be less than or equal to 500 m.
- A maximum of 240 optimizers can be connected to an inverter. The length of the cable between the optimizer at the end and the inverter cannot exceed 350 m.




Figure 2-3 RS485 networking application (Dongle)

## **MBUS Networking**

- A maximum of 80 inverters can be cascaded to each SmartLogger.
- If MBUS is used for communication, you are advised to use multi-core cables with the maximum communication distance of 1000 m. To use other types of AC power cables, contact local technical support.
- In the networking shown in **Figure 2-4**, the maximum number of optimizers is 4800
- A maximum of 240 optimizers can be connected to an inverter. The length of the cable between the optimizer at the end and the inverter cannot exceed 350 m.




Figure 2-4 MBUS networking application (SmartLogger)

- A maximum of 10 inverters can be cascaded to a Dongle.
- If MBUS is used for communication, you are advised to use multi-core cables with the maximum communication distance of 1000 m. To use other types of AC power cables, contact local technical support.
- In the networking shown in **Figure 2-5**, the maximum number of optimizers is 2400.
- A maximum of 240 optimizers can be connected to an inverter. The length of the cable between the optimizer at the end and the inverter cannot exceed 350 m.





Figure 2-5 MBUS networking application (Dongle)

# 2.2.2 Earthing Systems

The SUN5000 supports the TN-S, TN-C, TN-C-S, TT, and IT earthing systems.


Figure 2-6 Earthing systems



# 2.3 Appearance

## **Appearance and Ports**

Figure 2-7 Appearance



- (1) Panel
- (3) Maintenance compartment door
- (5) DC SWITCH 1
- (7) USB port
- (9) DC input terminal group 2 (PV10–PV21, controlled by DC SWITCH 2)
- (11) AC output cable hole

- (2) LED indicators
- (4) Fan tray
- (6) DC input terminal group 1 (PV1–PV9, controlled by DC SWITCH 1)
- (8) RS485 communication port (COM)
- (10) DC SWITCH 2
- (12) Ground point

## **Indicator Description**

Indicator	Status (Blinking Fast: On for 0.2s and Off for 0.2s; Blinking Slowly: On for 1s and Off for 1s)	Meaning
PV connection indicator	Steady green	At least one PV string is properly connected, and the DC input voltage of the corresponding MPPT circuit is at least 200 V.

Indicator	Status (Blinking Fast: On for 0.2s and Off for 0.2s; Blinking Slowly: On for 1s and Off for 1s)		Meaning
	Blinking green fast		If the alarm/maintenance indicator is red, an environmental fault at the DC side of the inverter was generated.
	Off		The inverter is disconnected from all PV strings, or the DC input voltage of all MPPT circuits is less than 200 V.
	Steady red		If the alarm/maintenance indicator is red, an internal fault on the DC side of the inverter is generated.
Grid	Steady green		The inverter is in grid-tied mode.
connection indicator	Blinking green fast		If the alarm/maintenance indicator is red, an environmental fault on the AC side of the inverter was generated.
	Off		The inverter is not in grid-tied mode.
	Steady red		If the alarm/maintenance indicator is red, an internal fault on the AC side of the inverter was generated.
Communicati on indicator	Blinking green	fast	The inverter receives communication data normally.
((()))	Off		The inverter has not received communication data for 10 seconds.
Alarm/ Maintenance indicator	ce Alarm Steady red		<ul> <li>A major alarm was generated.</li> <li>If the PV connection indicator or grid connection indicator is blinking green fast, rectify DC or AC environmental faults as instructed by the SUN2000 app.</li> <li>If neither the PV connection indicator nor the grid connection indicator is blinking green fast, replace components or the inverter as instructed by the SUN2000 app.</li> </ul>
		Blinking red fast	A minor alarm was generated.
		Blinking red slowly	A warning alarm was generated.
	Local	Steady green	The local maintenance is successful.
	maintenance	Blinking green fast	The local maintenance failed.

Indicator	Status (Blinking Fast: On for 0.2s and Off for 0.2s; Blinking Slowly: On for 1s and Off for 1s)		Meaning
		Blinking green slowly	The device is under local maintenance or shut down after receiving a command.

#### ■ NOTE

- The PV connection indicator and the grid connection indicator preferentially indicate environmental faults.
- Local maintenance refers to operations performed after a USB flash drive, WLAN module, or USB data cable is inserted into the USB port of the inverter. For example, import and export data using a USB flash drive, or connect to the app using a WLAN module or USB data cable.
- If the alarming and the local maintenance happen concurrently, the alarm/maintenance indicator shows the local maintenance state first. After the USB flash drive, WLAN module, or USB data cable is removed, the indicator shows the alarm state.

#### DC SWITCH


#### **⚠** DANGER

- If both DC switches are automatically turned off at the same time, the AC switch does not trip, and the indicators on the inverter display the following status, do not turn on the DC switches by yourself. Contact your vendor or technical support.
  - 1. LED1, LED2, and LED4 are steady red.
  - 2. LED1 and LED4 are steady red.
- If both DC switches are automatically turned off at the same time, the AC switch does not trip, and the LED4 indicator on the inverter is steady red, do not turn on the DC switches by yourself. Perform operations according to the handling suggestions for alarm ID 2001.
- If all DC switches are automatically turned off at the same time and the AC switch trips, check that no short circuit occurs on the AC side between phases or between a phase and the ground, turn on the AC switch, export logs, and send the logs to your vendor or technical support. Rectify the fault after your vendor or technical support provides a solution. If there is any short circuit on the AC side between phases or between a phase and the ground, do not turn on the AC switch. Contact your vendor or technical support.
- Before turning on a switch, ensure that all alarms have been cleared.
- If the DC switches are automatically turned off and the inverter generates a
   String Reverse Connection or String Current Backfeed alarm, rectify the fault
   based on the alarm handling suggestions. After the fault is rectified, wait for at
   least 3 minutes, turn the switch handle to OFF to complete the reset, and then
   turn it on. For details, see Resetting and Turning On the DC Switch.

Table 2 2 De 3WiTel Tueschphon		
Switch	Description	
DC ON SWITCH		The DC SWITCH is on and can be turned off for protection.
	TRIP	The DC SWITCH is automatically turned off. (The switch handle is between <b>ON</b> and <b>OFF</b> .)
	OFF	The DC SWITCH is off.

Table 2-2 DC SWITCH description

Figure 2-8 DC SWITCH
DC SWITCH



# 2.4 Circuit Diagram

The SUN5000 receives inputs from 21 PV strings. The inputs are grouped into 7 MPPT circuits inside the inverter to track the maximum power point of the PV strings. The DC power is converted into three-phase AC power through an inverter circuit. Surge protection is supported on both the DC and AC sides.


MPPT1 MPPT2 @ L1 Output Output EMI filter filter AC 013 МРРТ3 Output @ N AC SPD @ PE MPPT4 MPPT5 11-MPPT6 MPPT7

Figure 2-9 Circuit diagram

# 2.5 Working Modes

The SUN5000 has three working modes: standby, operating, and shutdown.

Figure 2-10 Working modes



IS07S00001

Table 2-3 Working mode description

Working Mode	Description
Standby mode	The inverter enters standby mode when the external environment does not meet the operating requirements. In standby mode:
	The inverter continuously detects its operation status. Once the operation conditions are met, the inverter enters operating mode.
	If the inverter receives a shutdown command or detects a fault after startup, it enters shutdown mode.

Working Mode	Description
Operating	In operating mode:
	The inverter converts DC power from PV strings into AC power and feeds the power to the power grid.
	The inverter tracks the maximum power point to maximize the PV string output power.
	If the inverter receives a shutdown command or detects a fault, it enters shutdown mode.
	If the inverter detects that the output power of PV strings does not meet the requirements for grid-tied power generation, it enters standby mode.
Shutdown	In standby or operating mode, if the inverter receives a shutdown command or detects a fault, it enters shutdown mode.
	In shutdown mode, if the inverter detects that the fault is rectified or receives a startup command, it enters standby mode.

# 2.6 Label Description

Symbol	Name	Meaning
	Large current warning	Potential hazards exist after the inverter is powered on. Take protective measures when operating the inverter. Before powering on the inverter, ensure that the inverter is grounded because there is a large contact current after the inverter is powered on.
	High temperature hazard	Do not touch the inverter when it is running because its enclosure is hot.
A	Electric shock hazard	Hazardous voltages exist when the inverter is working. Take protective measures during operations and maintenance.

Symbol	Name	Meaning
A C 15 mins	Delayed discharge	<ul> <li>High voltage exists after the inverter is powered on. Only qualified and trained electrical technicians are allowed to perform operations on the inverter.</li> <li>Residual voltage exists after the inverter is powered off. It takes 15 minutes for the inverter to discharge to the safe voltage.</li> </ul>
Ţ <b>i</b>	Referring to documentation	Reminds operators to refer to the documentation for the device. Losses caused by operations that do not comply with the requirements of site selection, storage, or mounting specified in the user manual are not covered under the warranty.
	Protective earthing	Indicates the position for connecting the protective earthing (PE) cable.
Do not disconnect under load! 禁止带负荷断开连接!	Operation warning	Do not remove the DC input connector when the inverter is running.
Before replacing the fan, disconnect the FAN-POWER cable and then the fan cable. 更换风扇前,必须先拔除风扇电源线,再拔除风扇线。	Fan operation warning	The power connector of the fan must be disconnected before fan replacement.
(1P)PN/ITEM:XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX	Inverter SN label	Indicates the inverter serial number.
or or > 55 kg (121 lbs)	Device weight	The inverter needs to be carried by four persons or using a forklift.
WARNING  After the DC switch is disconnected automatically, do not turn it on again, Perform operations according to least in formation and user manual.  遠定开美自命分報后,请勿重新研合,按照各署指示和用户字册进行操作	DC SWITCH operation label	After the DC SWITCH is automatically turned off, do not turn it on. Perform operations according to the alarm information and user manual.

Symbol	Name	Meaning
SAFEROOF	PV+optimizer label	The inverter must be used with optimizers.

# 3 Storage Requirements


#### **NOTICE**


- Store the device according to the storage requirements. Device damage caused by unqualified storage conditions is not covered under the warranty.
- Do not store the device without outer packaging.
- Do not tilt a packing case or place it upside down.

The following requirements shall be met if inverters are not put into use immediately:

- Do not remove the outer packaging. Check the packaging regularly (recommended: once every three months). Replace any packaging that is damaged during storage.
- If an inverter is unpacked but will not be used immediately, put it back to the original packaging with the desiccant, and seal it with tape.
- Inverters must be stored in a clean and dry environment with appropriate temperature and humidity. The air must not contain corrosive or flammable gases.

Figure 3-1 Storage temperature and humidity






IS07W0001

- When temporarily storing inverters outdoors, do not stack them on a pallet. Take rainproof measures such as using tarpaulins to protect inverters from rain and water.
- Do not tilt a packing case or place it upside down.

• To avoid personal injury or device damage, stack inverters with caution to prevent them from falling over.

Figure 3-2 Maximum number of stacking layers



- Do not store inverters for more than two years. If inverters have been stored for two years or longer, they must be checked and tested by professionals before being put into use.
- If an inverter has not been running for six months or longer after being mounted, it may have failed and must be checked and tested by professionals before being put into operation.

4 Installation

## 4.1 Installation Modes

The inverter can be mounted on a wall, support, or pole clamp.

Table 4-1 Installation modes

Installation Mode	Screw Specifications	Description
Wall mounting	M12x60 stainless steel expansion anchor bolt	Prepared by the customer
Support mounting	M12x40 bolt assembly	Delivered with the mounting bracket. If the length does not meet the installation requirements, the customer shall prepare M12 bolt assemblies and install them together with the M12 nuts delivered with the product.
Pole-clamp mounting	Depending on the pole clamp	Prepared by the customer

# 4.2 Installation Requirements

## 4.2.1 Site Selection Requirements

## **Installation Environment Requirements**

- Do not install the inverter in working or living areas to avoid personal injury or property loss caused by accidental contact by non-professionals or other reasons during device operation.
- Do not install the inverter in noise-sensitive areas (such as residential areas, office areas, and schools) to avoid complaints. If the preceding areas are unavoidable, the distance between the installation position and noisesensitive areas must be greater than 40 m. Alternatively, use other low-noise models.
- If the device is installed in public places (such as parking lots, stations, and factories) other than working and living areas, install a protective net outside the device and set up a safety warning sign to isolate the device. This is to avoid personal injury or property loss caused by accidental contact by non-professionals or other reasons during device operation.
- If the equipment is installed in a place with abundant vegetation, in addition to routine weeding, harden the ground underneath the equipment using cement or gravel (the area shall be greater than or equal to 3 m x 2.5 m).
- Do not install the equipment in an area with strong vibration, noise, or electromagnetic interference. The equipment shall be installed in an environment with a magnetic field strength less than 4 Gauss. If the magnetic field strength is greater than or equal to 4 Gauss, the equipment may fail to work properly. If the magnetic field strength is high, for example, in a smeltery, you are advised to use a gauss meter to measure the magnetic field strength of the equipment installation position when the smelting equipment is running normally.
- Do not install the inverter in areas containing flammable materials (such as sulfur, phosphorus, liquefied petroleum gas, marsh gas, flour, and cotton) to avoid personal injury or property loss caused by fire or other reasons.
- Do not install the inverter in areas containing explosives (such as blasting agents, display shells, fireworks, and firecrackers) to avoid personal injury or property loss caused by explosion or other reasons.
- Do not install the inverter in areas with corrosive substances (such as sulfuric acid, hydrochloric acid, nitric acid, hydrogen sulfide, and chlorine) to avoid inverter failure caused by corrosion, which is not covered under the warranty.
- Do not install the device where its enclosure and heat sink are easily accessible, because the voltage is high and these parts are hot during operation.
- The inverter provides self-protection in high-temperature environments. Its energy yield may decrease as the ambient temperature increases. Ensure that the following installation requirements are met:
  - Install the device in a well-ventilated environment to ensure good heat dissipation.
  - If the device is installed in an enclosed environment, the heat dissipation equipment or ventilation equipment shall be installed. The indoor ambient temperature must not be higher than the outdoor ambient temperature.

- You are advised to install the device in a sheltered place or install an awning over it to avoid direct sunlight.
- Reserve sufficient clearance around the inverter for installation and heat dissipation.
- The inverter will become corroded if installed in areas exposed to salt. Before installing the inverter outdoors in such areas, consult with the Company. A salt-affected area refers to a region within 500 m of the coast or prone to sea breeze. Regions prone to sea breeze vary with weather conditions (such as typhoons and monsoons) or terrains (such as dams and hills).
- The inverter is not intended for use in a residential environment or those directly connected to a low voltage power supply network which supplies buildings used for domestic purposes. When using in such environments, the inverter may not provide adequate protection to radio reception.
- The inverter is intended to be installed in a large photovoltaic power generating system by a professional.

#### 


The device shall be physically separated from residential environments or radio receivers by distance greater than 30 m, and can be equipped with additional filtering if necessary.

# **Mounting Structure Requirements**

- The mounting structure for the inverter must be fireproof. Do not install the inverter on flammable building materials to avoid personal injury or property loss caused by fire or other reasons.
- Ensure that the installation surface is solid enough to bear the weight of the device. to avoid personal injury or property loss caused by the collapse of the mounting structure or other reasons.
- In residential areas, do not install the device on plaster board walls or walls made of similar materials with a weak sound insulation performance because the noise generated by the device may interfere with residents.

Figure 4-1 Mounting structure








# 4.2.2 Clearance Requirements

### **Dimensions**


Figure 4-2 Dimensions



# **Installation Clearance Requirements**

Reserve sufficient clearance around the inverter for installation and heat dissipation.

Figure 4-3 Clearance




# □ NOTE

For ease of the inverter installation on the mounting bracket, cable connection at the bottom, and future maintenance, it is recommended that the clearance from the bottom be between 600 mm and 730 mm. For further questions regarding clearance, consult local technical support engineers.

When installing multiple inverters, install them in horizontal mode if sufficient space is available and install them in triangle mode if no sufficient space is available. Stacked installation is not recommended.

Figure 4-4 Horizontal installation mode (recommended)



≥ 800 mm ≥ 500 mm

Figure 4-5 Triangle installation mode (recommended)

Figure 4-6 Back-to-back installation mode (recommended)





Figure 4-7 Stacked installation mode (not recommended)




# 4.2.3 Angle Requirements

The inverter can be support-mounted or wall-mounted. The installation angle requirements are as follows:

- Install the inverter vertically or at a maximum back tilt of 75 degrees to facilitate heat dissipation.
- Do not install the inverter at forward tilted, excessive back tilted, side tilted, horizontal, or upside down positions.

Figure 4-8 Installation angle



# 4.3 Preparing Tools

Category	Tool			
			A	<b>+</b>
	Hammer drill	Drill bit (Φ14 mm and Φ16 mm)	Insulated torque socket wrench (including an extension bar ≥ 50 mm)	Phillips insulated torque screwdriver
	Flat-head insulated torque screwdriver	Wire stripper	Diagonal pliers	Rubber mallet
Installation	50000			9. 103
	Utility knife	Cable cutter	Crimping tool H4STC0001 (AMPHENOL) or CT75A-FJB10 (AVIC JONHON)	Spanner H4TW0001 (AMPHENOL) or CT75A-FJB7 (AVIC JONHON)
	RJ45 crimping tool	Vacuum cleaner	Multimeter (DC voltage measurement range ≥ 1100 V DC)	Marker

Category	Tool			
		<b>2</b> ○		
	Steel measuring tape	Level	Hydraulic pliers	Heat shrink tubing
		0		
	Heat gun	Cable tie	Scissors	Insulation resistance tester (output voltage > 1500 V)
Personal protective	Insulated gloves	Goggles	Dust mask	Insulated shoes
equipment (PPE)				-
	Safety helmet	Reflective vest	Protective gloves	

# 4.4 Checking Before Installation

# **Outer Packing Materials**

Before unpacking the inverter, check the outer packing materials for damage, such as holes and cracks, and check the inverter model. If any damage is found or the inverter model is not what you requested, do not unpack the package and contact your supplier as soon as possible.

# □ NOTE

You are advised to remove the packing materials within 24 hours before installing the inverter.

# **Package Contents**

#### NOTICE

• After placing the equipment in the installation position, unpack it with care to prevent scratches. Keep the equipment stable during unpacking.

After unpacking the inverter, check that the contents are intact and complete. If any damage is found or any component is missing, contact your supplier.

#### □ NOTE

For details about the number of contents, see the *Packing List* in the packing case.

# 4.5 Moving the Inverter


### **Procedure**

**Step 1** Take the inverter out of the packing case and move it to the installation position.

#### NOTICE


- After placing the equipment in the installation position, unpack it with care to prevent scratches. Keep the equipment stable during unpacking.
- Handles are packed in a fitting bag and are not delivered with the inverter.
- Secure the lifting handles (with the steel washers of the lifting handles closely fitted to the inverter).
- If the stud of a lifting handle is bent, replace the lifting handle in time.
- Four persons or appropriate transportation tools are required to move the inverter.
- Do not use the ports or wiring terminals at the bottom to support any weight of the inverter.
- When you need to temporally place the inverter on the ground, use foam, cardboard, or other protection material to prevent damage to its enclosure.
- To avoid damage to the inverter, do not lift or hoist it with an improper hold as shown in Figure 4-10.

Figure 4-9 Taking out, moving, or mounting the inverter



- (A) Taking out the inverter
- (B) Installing the lifting (C) Moving the handles inverter
- (D) Mounting the inverter


Figure 4-10 Lifting positions



# **MOTE**

If the installation position is high, you can hoist the inverter.

Figure 4-11 Hoisting




----End

# 4.6 Installing the Inverter on a Support

# **Procedure**

**Step 1** Remove the torx key and store it properly.

Figure 4-12 Removing the torx key




**Step 2** Secure the mounting bracket.

#### □ NOTE

- The mounting bracket of the inverter has four groups of tapped holes, each group containing four tapped holes. Mark any hole in each group based on site requirements and mark four holes in total. The two round holes are recommended.
- M12x40 bolt assemblies are delivered with the inverter and bound to the mounting bracket. If the bolt length does not meet the installation requirements, prepare M12 bolt assemblies by yourself and use them together with the delivered M12 nuts.

Figure 4-13 Installing the mounting bracket



**Step 3** Secure the inverter.

Figure 4-14 Securing the inverter

----End

# 4.7 Installing the Inverter on a Wall


# **Procedure**

- **Step 1** Determine the hole positions and mark them using a marker.
- **Step 2** Secure the mounting bracket.



Avoid drilling holes into the water pipes or power cables buried in the wall.

Figure 4-15 Expansion bolt structure



IS05W00018

(1) Bolt


(2) Nut

(3) Spring washer

- (4) Flat washer
- (5) Expansion sleeve


- To prevent dust inhalation or contact with eyes, wear safety goggles and a dust mask when drilling holes.
- Use a vacuum cleaner to clean up dust in and around the holes, and measure the spacing. If the holes are inaccurately positioned, drill the holes again.
- Level the top of the expansion sleeve with the concrete wall after removing the nut, spring washer, and flat washer. Otherwise, the mounting bracket will not be securely installed on the concrete wall.

Figure 4-16 Installing an expansion bolt



**Step 3** Secure the inverter.


Figure 4-17 Securing the inverter



----End

# 4.8 Installing the Inverter on a Pole Clamp

Figure 4-18 Pole-clamp installation



# 5 Electrical Connections

# 5.1 Precautions

### **⚠** DANGER

- When exposed to sunlight, the PV arrays supply DC voltage to the inverter.
   Before connecting cables, ensure that each DC SWITCH on the inverter is set to OFF. Otherwise, the high voltage of the inverter may result in electric shocks.
- The site must be equipped with qualified fire fighting facilities, such as fire sand and carbon dioxide fire extinguishers.
- Wear personal protective equipment and use dedicated insulated tools to avoid electric shocks or short circuits.

# **⚠ WARNING**

- The equipment damage caused by incorrect cable connections is beyond the warranty scope.
- Only certified electrician can perform electrical terminations.
- Operation personnel must wear PPE when connecting cables.
- Before connecting cables to ports, leave enough slack to reduce the tension on the cables and prevent poor cable connections.

# **A** CAUTION

• Stay away from the equipment when preparing cables to prevent cable scraps from entering the equipment. Cable scraps may cause sparks and result in personal injury and equipment damage.

# **MOTE**

The cable colors shown in the electrical connection diagrams provided in this section are for reference only. Select cables in accordance with local cable specifications (green-and-yellow cables are only used for protective earthing).

# **5.2 Preparing Cables**

**Figure 5-1** Cable connections (configure the components in the dotted box as required)




Table 5-1 Component description

No.	Component	Description	Source
А	PV module	PV modules need to connect to optimizers before connecting to the	Prepared by the customer
В	Optimizer	<ul><li>inverter.</li><li>The inverter supports a maximum of 12 PV string inputs.</li></ul>	Purchased from the Company
С	SmartLogger	The SUN5000 communicates with the management system through the SmartLogger.	Purchased from the Company
D	SUN5000	Select a proper model as required.	Purchased from the Company

No.	Component	Description	Source
Е	Power meter <sup>[1]</sup>	Implements power control at the grid connection point in low voltage scenarios using a power meter.  Recommended power meter models: DTSU666-HW; YDS60-80	Prepared by the customer
F	AC switch	To ensure that the inverter can be safely disconnected from the power grid when an exception occurs, connect an AC switch to the AC side of the inverter. Select an appropriate AC switch in accordance with local industry standards and regulations.  • Installed in the AC combiner box	Prepared by the customer
		<ul> <li>Recommended: a three-phase AC circuit breaker with a rated voltage greater than or equal to 500 V AC and a rated current of 315 A</li> </ul>	
G	Dongle	The SUN5000 communicates with the management system through the Dongle.	Purchased from the Company

Note [1]: For details about power meter operations, see **DTSU666-HW Smart Power Sensor Quick Guide** and **YDS60-80 Smart Power Sensor Quick Guide**.

### NOTICE

The inverter has an internal residual current monitoring unit (RCMU). Its external AC switch should be a three-phase circuit breaker or any other AC load circuit breaker to safely disconnect the inverter from the power grid.

#### □ NOTE

- Select cables in compliance with local cable standards.
- The factors that affect cable selection include the rated current, cable type, routing mode, ambient temperature, and maximum expected line loss.

**Table 5-2** Cable description (S indicates the conductor cross-sectional area of the AC cable, and  $S_p$  indicates the conductor cross-sectional area of the PE cable)

No.	Cable	Туре	Conductor Cross-Sectional Area	Outer Diameter	Source
1	PE cable <sup>[1]</sup>	Single-core outdoor copper cable and M10 OT/DT terminal	S <sub>p</sub> ≥ S/2	-	Prepared by the customer

No.	Cable	Туре	Conductor Cross-Sectional Area	Outer Diameter	Source
2	DC input power cable	PV cable that meets the 1100 V standard	4–6 mm <sup>2</sup>	5.5–9 mm	Prepared by the customer

No.	Cable	Туре	Conductor Cross-Sectional Area	Outer Diameter	Source
3	AC output power cable (multi-core)	<ul> <li>If you connect a PE cable to the ground point on the enclosure and no neutral wire is used, you are advised to use a three-core (L1, L2, and L3) outdoor cable and M12 OT/DT terminals (L1, L2, and L3).</li> <li>If you connect a PE cable to the ground point in the maintenance compartment and no neutral wire is used, you are advised to use a four-core (L1, L2, L3, and PE) outdoor cable, M12 OT/DT terminals (L1, L2, and L3), and M10 OT/DT terminals (PE).</li> <li>If you connect a PE cable to the ground point on the enclosure and a neutral wire is used, you are advised to use a four-core (L1, L2, L3, and N) outdoor cable and M12 OT/DT terminals (L1, L2, L3, and N).</li> <li>If you connect a PE cable to the ground point in the maintenance compartment and a neutral wire is used, you are advised to use a five-core (L1, L2, L3, and N).</li> <li>If you connect a PE cable to the ground point in the maintenance compartment and a neutral wire is used, you are advised to use a five-core (L1, L2, L3, N, and PE) outdoor cable, M12 OT/DT terminals (L1, L2, L3, N, and PE) outdoor cable, M12 OT/DT terminals (L1, L2, L3, N, and M10</li> </ul>	<ul> <li>S: 95-240 mm²</li> <li>S<sub>p</sub> ≥ S/2</li> </ul>	24-66 mm	Prepared by the customer
	1	OT/DT terminals (PE).			

No.	Cable	Туре	Conductor Cross-Sectional Area	Outer Diameter	Source
	AC output power cable (single-core)	(Recommended) Single- core outdoor cable and M12 OT/DT terminal	<ul> <li>S: 95-400 mm<sup>2</sup></li> <li>S<sub>p</sub> ≥ S/2</li> </ul>	14–38 mm	Prepared by the customer
4	RS485 communicatio ns cable	Outdoor shielded twisted pair cable that meets the local standard	0.25–1 mm <sup>2</sup>	<ul> <li>One or two communic ations cables: 4–11 mm</li> <li>Three communic ations cables: 4–8 mm</li> </ul>	Prepared by the customer

Note [1]: The  $S_p$  value is valid only if the conductors of the PE cable and AC output power cable use the same material. If the materials are different, ensure that the conductor cross-sectional area of the PE cable produces a conductance equivalent to that specified in this table. The specifications of the PE cable are subject to this table or calculated according to IEC 60364-5-54.

# 5.3 Connecting a PE Cable

# **Precautions**

#### **DANGER**

- Ensure that the PE cable is securely connected. Otherwise, electric shocks may occur.
- Do not connect the neutral wire to the enclosure as a PE cable. Otherwise, electric shocks may occur.


- Proper grounding is helpful for resisting the impact of surge voltage and improving the electromagnetic interference (EMI) performance. Before connecting the AC power cable, DC power cables, and communications cable, connect the PE cable to the PE point.
- You are advised to connect the PE cable to the PE point on the enclosure. The
  PE point in the maintenance compartment is used for connecting to the PE wire
  of a multi-core AC power cable. If the cross-sectional area of the PE cable
  meets the requirements, select either PE point on the enclosure or in the
  maintenance compartment for connecting the PE cable.
- It is recommended that the inverter be connected to a nearby PE point.

  Connect the PE points of all inverters in the same array to ensure equipotential connections to PE cables.

### **Procedure**

**Step 1** Connect the PE cable to the PE point. To enhance the corrosion resistance of a PE terminal, apply silicone grease or paint on it after connecting the PE cable to the PE point on the enclosure.

Figure 5-2 Connecting a PE cable to the PE point (on the enclosure)



----End

# 5.4 Connecting an AC Output Power Cable

### **Precautions**

- A three-phase AC switch should be installed on the AC side of the inverter. To ensure that the inverter can safely disconnect itself from the power grid when an exception occurs, select a proper overcurrent protection device in compliance with local power distribution regulations.
- The inverter is integrated with a comprehensive residual current detection unit to distinguish fault current from residual current. Upon detecting that the residual current exceeds the threshold, the inverter immediately disconnects from the power grid.

# **MARNING**

- Do not connect loads between an inverter and an AC switch that directly connects to the inverter. Otherwise, the switch may trip by mistake.
- If an AC switch is used with specifications beyond local standards, regulations, or the Company's recommendations, the switch may fail to turn off in a timely manner in case of exceptions, causing serious faults.
- Do not open the panel of the inverter.
- Do not open the maintenance compartment door on rainy or snowy days. If you need to, take protective measures to prevent rain or snow from entering the maintenance compartment. If protective measures cannot be taken, do not open the maintenance compartment door.
- Do not open the maintenance compartment door on rainy or snowy days. If you need to, take protective measures to prevent rain or snow from entering the maintenance compartment. If protective measures cannot be taken, do not open the maintenance compartment door.
- Do not leave unused screws in the maintenance compartment.

# **♠** CAUTION

Each inverter shall be equipped with an AC output switch. Multiple inverters shall not connect to the same AC switch.

# **<u>A</u>** CAUTION

Cables must be vertically routed into the maintenance compartment, PV terminals, and other wiring terminals to avoid damage caused by horizontal stress on the terminals, which is not covered under the warranty.


- The cable outer diameter can be measured using the ruler sticker in the maintenance compartment.
- Ensure that the cable jacket is in the maintenance compartment.
- If you remove too many parts of the rubber ring of a cable, making the cable hole diameter greater than the cable outer diameter, use firestop putty to seal the gap around the rubber ring of the cable.
- Ensure that the AC output power cables are connected securely. Otherwise, the inverter may fail to operate, or become overheated during operation due to an unreliable connection, which will damage the terminal block. The resulting device damage is not covered under any warranty.
- You are advised to connect the PE cable to the PE point on the enclosure. The
  PE point in the maintenance compartment is used for connecting to the PE wire
  of a multi-core AC power cable. If the cross-sectional area of the PE cable
  meets the requirements, select either PE point on the enclosure or in the
  maintenance compartment for connecting the PE cable.

**Table 5-3** Bending radius requirements for AC power cables

Picture	Single-core Cable		Multi-core Cable	
	Unarmored	Armored	Unarmored	Armored
	R ≥ 20D	R ≥ 15D	R ≥ 15D	R ≥ 12D
•	R indicates the bending radius, and D indicates the outer diameter of the cable.			
D R R IS18W00015	NOTE  The AC power cable must be routed vertically into the maintenance compartment.			

# Wiring Area


Figure 5-3 Wiring ports



# **Procedure**


**Step 1** Open the maintenance compartment door and install the door stopper.

Figure 5-4 Opening a maintenance compartment door



**Step 2** Connect the AC output power cables based on the cable type.

Figure 5-5 Specifications of the crimped OT/DT terminal



A

M12 (L1/L2/L3/N)

M10 (PE)

Figure 5-6 Cable connection

(A) Single-core cable

D

(B) Four-core cable (including the neutral wire)

E

luding (C) Five-core cable

40-45 N·m

15 N·m

- (D) Three-core cable
- (E) Four-core cable (including the PE wire)

# NOTICE

- Reserve sufficient slack for the PE wire to ensure that the PE wire is the last cable bearing the force when the AC output power cable is subject to a pulling force due to force majeure.
- After cables are connected, prevent them from contacting the inter-phase baffle plates.




Figure 5-7 Single-core cable connection


If a multi-core cable is used, it is recommended that the stripping length of the L2 wire be 15 mm shorter than those of the L1 and L3 wires.

D: 24-25 mm
D: 25-37 mm
D: 46-55 mm
D: 55-64 mm
D: 64-66 mm

Figure 5-8 Multi-core cable connection (using a five-core cable as an example)

**Step 3** Clear foreign matter from the maintenance compartment, close the maintenance compartment door, and check that the cable holes at the bottom of the maintenance compartment are sealed.

Figure 5-9 Closing a door



# **5.5 Connecting DC Input Power Cables**

# 5.5.1 Measuring the Insulation Resistance of PV Strings to the Ground

Before connecting PV strings to the inverter, ensure that the insulation resistance of each PV string to the ground is normal. The following figure shows the measuring method.

**Step 1** Connect the positive and negative output connectors of a PV string to a branch cable, and use an insulation resistance tester to test the insulation resistance of the PV string cable to the ground: Add a DC voltage greater than 1000 V between the cable and the ground, and check the insulation resistance.

If	Then
Insulation resistance ≥ 200 MΩ	The PV string is normal.
Insulation resistance < 200 M $\Omega$	You need to check the insulation of the cable or PV string. Go to <b>Step 2</b> .




Figure 5-10 Testing the insulation resistance

**Step 2** Disconnect the suspected faulty PV module and the paired optimizer from the PV string. Keep the optimizer connected to the PV module and measure the ground resistance of the optimizer.

If	Then
Insulation resistance ≥ 200 MΩ	If the disconnected optimizer and PV module are normal, perform <b>Step 2</b> for another PV module and the paired optimizer.
Insulation resistance < 200 $M\Omega$	The optimizer, PV module, or both are faulty. Go to <b>Step 3</b> for troubleshooting.

**Step 3** Check whether the PV module or optimizer is faulty by testing each component separately:

- 1. Disconnect the PV module from the optimizer
- Connect the output positive and negative connectors of the power optimizer
  to a branch cable, and then connect the cable to the positive probe of the
  insulation tester. Connect the negative probe of the insulation tester to the
  ground. Measure the insulation resistance of the optimizer.

If	Then
Insulation resistance ≥ 200 MΩ	The optimizer is normal, but the PV module is faulty.

If	Then
Insulation resistance < 200 $M\Omega$	The optimizer is faulty.  After replacing the optimizer, check whether the PV module is also faulty.

3. Measure the insulation resistance of the PV module. You are advised to consult the PV module manufacturer to determine whether the PV module is abnormal.

#### 

For a PV module without an optimizer, you do not need to use a branch cable to connect PV+ and PV-. Instead, measure the insulation resistance at the positive and negative poles of the PV module separately.

4. Replace the faulty PV module or optimizer.

----End

# 5.5.2 Connecting DC Input Power Cables

#### **Precautions**

### **⚠** DANGER

- Before connecting the DC input power cables, ensure that the DC voltage is within the safety voltage range (lower than 60 V DC) and that each DC SWITCH of the inverter is OFF. Otherwise, the high voltage may result in electric shocks.
- When the inverter operates in grid-tied mode, do not perform maintenance or operations on the DC input power cables, such as connecting or disconnecting a PV string or a PV module in the PV string. Otherwise, electric shocks or arcing (which may cause fire) may occur.
- For details about how to remove and insert DC input connectors, see 8.3
   Power-Off for Maintenance.

# **MARNING**

Ensure that the following conditions are met. Otherwise, the inverter may be damaged or even a fire may occur.

- The polarities of electrical connections must be correct on the DC input side. The positive and negative terminals of a PV string must be connected to corresponding positive and negative DC input terminals of the inverter.
- The inverter must be connected to an optimizer. Otherwise, the inverter cannot work properly. For details about the configuration principles for inverters and optimizers, see MERC Smart PV Optimizer User Manual.

# **MARNING**

During the installation of PV strings and the inverter, the positive or negative terminals of PV strings may be short-circuited to ground if the power cables are not properly installed or routed. In this case, an AC or DC short circuit may occur and damage the inverter. The resulting device damage is not covered under any warranty.

# **!** CAUTION

Take waterproof and insulation measures for unused DC power cables to avoid personal injury or property loss caused by accidental contact with high voltage or other reasons.

### **NOTICE**

- Ensure that the PV string output is well insulated to ground.
- The maximum power of a PV string is 20 kW. The power difference between PV strings shall be less than or equal to 2 kW.
- The number of optimizers connected in series in a PV string ranges from 12 to 20.
- The PV strings connected in parallel in each MPPT circuit must use PV modules of the same model, quantity, and tilt angle.
- Each MPPT circuit can connect to a maximum of two PV strings.
- If some PV modules in a PV string are shaded, it is recommended that the PV string be connected to an MPPT circuit separately
- The inverter does not support full parallel connection for PV strings (full parallel connection: PV strings connect to one another in parallel outside the inverter and then connect to it separately).

# **Terminal Description**

The inverter provides 21 DC input terminals, which are controlled by its two DC switches: DC SWITCH 1 controls the DC input terminals PV1-PV9 and DC SWITCH 2 controls the DC input terminals PV10-PV21.

Figure 5-11 DC terminals controlled by DC SWITCH 1





Figure 5-12 DC terminals controlled by DC SWITCH 2





The number of PV strings with optimizers connected to the inverter ranges from 9 to 12. The PV strings with optimizers must be evenly distributed on each MPPT circuit. Based on the capacity ratio of an inverter, the following connection sequence is recommended.

Quantity of PV Strings	Capacity Ratio	Terminal Selection
9	0.8–1.0	PV1/2/4/9/10/13/18/20/21
10	1.0-1.1	PV1/2/4/9/10/13/17/18/20/21
11	1.1–1.2	PV1/2/4/5/9/10/13/17/18/20/21
12	1.2–1.6	PV1/2/4/5/8/9/10/13/17/18/20/21

### **Procedure**

#### NOTICE

- Use the PV connectors delivered with the inverter. If the PV connectors are lost or damaged, purchase the connectors of the same model. The device damage caused by incompatible PV connectors is not covered under any warranty.
- Connect the connectors on the PV strings to the connectors on the inverter, and pull back the connectors on the PV strings along the axial direction to check whether the connectors are securely installed.
- Ensure that the connectors are properly connected. Any connector damage due to improper connection is not covered under any warranty.
- Step 1 Install optimizer cables. For details, see MERC-(1300W, 1100W)-P Smart PV Optimizer Quick Guide.
- **Step 2** Before connecting PV strings to the inverter, ensure that the insulation resistance of each PV string to the ground is normal.
- **Step 3** Connect DC input power cables.




Figure 5-13 Connecting DC input power cables

- When installing DC input power cables, leave at least 150 mm of slack. The axial tension on PV connectors must not exceed 80 N. Radial stress or torque must not be generated on PV connectors.
- The PV string voltage value shall be equal to the quantity of optimizers.

**Step 4** Use sealing plugs with snap-fits to seal the DC input terminals that are not connected to PV strings. Device damage caused by the absence of sealing plugs is not covered by warranty.

Figure 5-14 Sealing plugs with snap-fits



SUN5000-150K-MG0-ZH

Sealing plug+/Sealing plug-: CT75A-FJB6/

CT75A-FJB5

SUN5000-150K-MG0 Sealing plug+/Sealing plug-: HY024-FHG-3/

HY024-FHG-4

----End


# **5.6 Connecting Signal Cables**

# **Precautions**

When routing communications cables, separate communications cables from power cables to prevent communication from being affected.

# **COM Port Pin Definitions**

Figure 5-15 Communications port



Port	Pin	Definition	Pin	Definition	Description
RS485-1	1	RS485A IN, RS485 differential signal+	2	RS485A OUT, RS485 differential signal+	Used to cascade inverters or connect devices such as the SmartLogger.
	3	RS485B IN, RS485 differential signal–	4	RS485B OUT, RS485 differential signal–	
PE	5	PE, shield layer grounding	6	PE, shield layer grounding	-

Port	Pin	Definition	Pin	Definition	Description
RS485-2	7	RS485A, RS485 differential signal+	8	RS485B, RS485 differential signal-	Connect to the RS485 signal port of devices such as a power meter.

# **Procedure**

**Step 1** Connect the RS485 communications cables.

8-10 mm D 4-8 mm 8-11 mm RS485A OUT RS485A IN RS485B IN RS485B OUT RS485A М3 0,5 N m  $\Theta$ COM COM

Figure 5-16 Connecting communications cables

IS18H00018

Use a plug to block the unused cable hole with the waterproof rubber ring, and then tighten the locking cap.

----End

# 5.7 (Optional) Installing the Smart Dongle

4G Smart Dongle

### NOTICE

- If your Smart Dongle is not configured with a SIM card, you need to prepare one (dimensions: 25 mm x 15 mm; capacity: ≥ 64 KB).
- When installing the SIM card, determine its installation direction based on the silk screen and arrow on the card slot.
- For details about SIM card traffic requirements, see FusionSolar Smart PV
   Management System Connection User Manual (Inverters + SDongle).
- In the Dongle networking of the SUN5000-150K-MG0-ZH, the demand for data traffic will be high. In that case, you are advised to use the Dongle without a data card and purchase a SIM card that meets the traffic requirements.
- Press the SIM card in place to lock it, indicating that the SIM card is correctly installed.
- When removing the SIM card, push it inward to eject it.
- When reinstalling the enclosure of the Smart Dongle, ensure that the snapfits click into place.





Figure 5-17 Installing the 4G Smart Dongle (SDongleB-06)

IL04H00043


• WLAN-FE Smart Dongle (WLAN communication)

**Figure 5-18** Installing the WLAN-FE Smart Dongle (SDongleA-05 for the WLAN communication scenario)



WLAN-FE Smart Dongle (FE communication)

**Figure 5-19** Installing the WLAN-FE Smart Dongle (SDongleA-05 for the FE communication scenario)



Install the network cable before installing the Smart Dongle on the inverter.

### **◯** NOTE

For details about how to use the WLAN-FE Smart Dongle SDongleA-05, see
 SDongleA-05 Smart Dongle Quick Guide (WLAN-FE). You can scan the QR code below to obtain the guide.



For details about how to use the 4G Smart Dongle SDongleB-06, see SDongleB-06
 Smart Dongle Quick Guide (4G). You can scan the QR code below to obtain the guide.



The quick guide is delivered with the Smart Dongle.

# 6 Checking Before Power-On

Table 6-1 Checklist

No.	Check Item	Acceptance Criteria
1	Inverter	The inverter is installed correctly and securely.
2	Smart Dongle	The Smart Dongle is installed correctly and securely.
3	Cable routing	Cables are routed properly as required by the customer.
4	Cable tie	Cable ties are evenly distributed and no sharp edge exists.
5	Grounding	The PE cable is connected correctly, securely, and reliably.
6	Switch	All <b>DC SWITCH</b> and other switches connected to the inverter are turned off.
7	Cable connection	The AC output power cable, DC input power cables, and signal cables are connected correctly and securely.
8	Unused terminal and port	Unused terminals and ports are locked by waterproof glands.
9	Installation environment	The installation space is proper, and the installation environment is clean and tidy.

# Power-On and Commissioning

#### **DANGER**

 Wear personal protective equipment and use dedicated insulated tools to avoid electric shocks or short circuits.

# 7.1 Powering On the Inverter

#### **Precautions**

### **MARNING**

When LED2 is steady green (the inverter is connected to the grid), do not turn on the DC switch. Otherwise, the inverter may be damaged because insulation resistance detection is not performed. You must power off the inverter first, and then turn on the DC switch and restart the inverter.

#### **NOTICE**

- Before the inverter is put into operation for the first time, ensure that the parameters are set correctly by professional personnel. Incorrect parameter settings may result in noncompliance with local grid connection requirements and affect the normal operations of the device.
- If the DC power supply is connected but the AC power supply is disconnected, the inverter will report the **Shutdown: Fault** fault. The inverter can start properly only after the fault is automatically rectified.
- The DC switches implement automatic disconnection. If cables are reversely connected, PV modules are not properly configured, or an internal fault occurs in the inverter, the DC switches automatically turn off for protection. In this case, rectify the fault as prompted on the app, check that the alarm is cleared, and then turn on the DC switches. Device damage caused by forcible switch-on after the DC switches turn off is not covered by the warranty. (If the DC switches automatically turn off due to an internal fault of the inverter, the Device Fault alarm will be reported. Do not turn on the DC switches again. Perform operations according to the alarm indication.)
- When the system is powered on or running, ensure that there are no obstacles in path of travel of the DC switch handles (for example, the handles are not stuck by cables or mistakenly held by hands) to ensure that the handles can move freely. Otherwise, the DC switches cannot automatically turn off.
- If an inverter has not been running for more than half a year after being mounted, it must be checked and tested by professionals before being put into operation.

#### **Procedure**

- **Step 1** At the AC switch between the inverter and the power grid, use a multimeter to measure the grid voltage and ensure that the voltage is within the allowed operating voltage range of the inverter. If the voltage is not in the allowed range, check the circuits.
- Step 2 Turn on the AC switch between the inverter and the power grid.
- **Step 3** Set **DC SWITCH 1** at the bottom of the inverter to **ON**. When you hear a click, the switch is on.
- **Step 4** Check the status of the PV connection indicator. When the PV connection indicator is steady green, set **DC SWITCH 2** to **ON**.
- **Step 5** Observe the LED indicators to check the status of the inverter.

Indicator	Status (Blinking Fast: On for 0.2s and Off for 0.2s; Blinking Slowly: On for 1s and Off for 1s)		Meaning
PV connection indicator	Steady green		At least one PV string is properly connected, and the DC input voltage of the corresponding MPPT circuit is at least 200 V.
	Blinking green	fast	If the alarm/maintenance indicator is red, an environmental fault at the DC side of the inverter was generated.
	Off		The inverter is disconnected from all PV strings, or the DC input voltage of all MPPT circuits is less than 200 V.
	Steady red		If the alarm/maintenance indicator is red, an internal fault on the DC side of the inverter is generated.
Grid	Steady green		The inverter is in grid-tied mode.
connection indicator	Blinking green fast		If the alarm/maintenance indicator is red, an environmental fault on the AC side of the inverter was generated.
	Off		The inverter is not in grid-tied mode.
	Steady red		If the alarm/maintenance indicator is red, an internal fault on the AC side of the inverter was generated.
Communicati on indicator	Blinking green	fast	The inverter receives communication data normally.
	Off		The inverter has not received communication data for 10 seconds.
Alarm/ Maintenance indicator	Alarm Steady red		<ul> <li>A major alarm was generated.</li> <li>If the PV connection indicator or grid connection indicator is blinking green fast, rectify DC or AC environmental faults as instructed by the SUN2000 app.</li> <li>If neither the PV connection indicator nor the grid connection indicator is blinking green fast, replace components or the inverter as instructed by the SUN2000 app.</li> </ul>
		Blinking red fast	A minor alarm was generated.
		Blinking red slowly	A warning alarm was generated.

Indicator	Status (Blinking Fast: On for 0.2s and Off for 0.2s; Blinking Slowly: On for 1s and Off for 1s)		Meaning
	Local maintenance	Steady green	The local maintenance is successful.
		Blinking green fast	The local maintenance failed.
		Blinking green slowly	The device is under local maintenance or shut down after receiving a command.

**Step 6** (Optional) Observe the Smart Dongle LED indicator to check the status of the Smart Dongle.

WLAN-FE Smart Dongle

**Table 7-1** LED indicators

LED Indicator	Status	Remarks	Description
-	Off	Normal	The Smart Dongle is not secured or is not powered on.
Yellow (steady green and red simultaneousl y)	Steady on		The Smart Dongle is secured and powered on.
Red	Blinking fast (on for 0.2s and then off for 0.2s)		The parameters for accessing the router have not been set.
Red	Steady on	Abnorma l	Replace the Smart Dongle because it has an internal fault.

LED Indicator	Status	Remarks	Description
Blinking red and green	Blinking slowly (on for 1s and	Abnorma l	Communication with the inverter fails.
alternatively	then off for 1s)		<ul> <li>Remove and insert the Smart Dongle.</li> </ul>
			<ul> <li>Check whether the inverter matches the Smart Dongle.</li> </ul>
			<ul> <li>Connect the Smart         Dongle to another         inverter.         Check whether the         Smart Dongle is faulty or         the USB port of the         inverter is faulty.     </li> </ul>
Green	Blinking slowly (on for 0.5s on and off for 0.5s)	Normal	The device is accessing the router.
Green	Steady on		Connection to the management system is successful.
Green	Blinking fast (on for 0.2s and then off for 0.2s)		The inverter is communicating with the management system through the Smart Dongle.

#### • 4G Smart Dongle

**Table 7-2** LED indicators

LED Indicator	Status	Remarks	Description
-	Off	Normal	The Smart Dongle is not secured or is not powered on.
Yellow (steady green and red simultaneousl y)	Steady on	Normal	The Smart Dongle is secured and powered on.
Green	The indicator blinks at an interval of 2s, on for 0.1s and then off for 1.9s.	Normal	The dial-up connection is in progress for less than 1 minute.

LED Indicator	Status	Remarks	Description
		Abnorma l	If the duration is longer than 1 minute, the 4G parameter settings are incorrect. Reset the parameters.
	Blinking slowly (on for 1s and then off for 1s)	Normal	The dial-up connection is set up successfully (duration < 30s).
		Abnorma l	If the duration is longer than 30s, the settings of the management system parameters are incorrect. Reset the parameters.
	Steady on	Normal	Connection to the management system is successful.
	Blinking fast (on for 0.2s and then off for 0.2s)		The inverter is communicating with the management system through the Smart Dongle.
Red	Steady on	Abnorma l	Replace the Smart Dongle because it has an internal fault.
	Blinking fast (on for 0.2s and then off for 0.2s)		The Smart Dongle has no SIM card or the SIM card is in poor contact. Check whether the SIM card has been installed or is in good contact. If not, install the SIM card, or remove and insert the SIM card.

LED Indicator	Status	Remarks	Description
	Blinking slowly (on for 1s and then off for 1s)		The Smart Dongle fails to connect to the management system because the SIM card runs out of the data quota or the signal strength is poor. If the Smart Dongle is reliably connected, check the SIM card signal through the app. If no signal is received or the signal strength is weak, contact the carrier. Check whether the tariff and data quota of the SIM card are normal. If not, top up the SIM card or purchase a data package.
Blinking red and green alternatively	Blinking slowly (on for 1s and then off for 1s)		Communication with the inverter fails.  Remove and insert the Smart Dongle.  Check that the inverter matches the Smart Dongle.  Connect the Smart Dongle to another inverter. Check whether the Smart Dongle is faulty or the USB port of the inverter is faulty.

----End

# 7.2 Commissioning Methods and Process

The inverter can be commissioned on the SmartLogger WebUI or FusionSolar app.




Figure 7-1 Commissioning process on the SmartLogger WebUI

App Download and Installation

Installer Registration

New Plant Deployment

End

Figure 7-2 Commissioning process on the FusionSolar app

# 7.3 Commissioning the SUN5000 (Using the SmartLogger)

# 7.3.1 Preparations and SmartLogger WebUI Login

For details about preparations and WebUI login, see **SmartLogger3000 User Manual**.

### 7.3.2 Software Upgrade

For details about software upgrade, see the SmartLogger3000 User Manual.

# 7.3.3 Commissioning Using the Deployment Wizard

#### **Procedure**

**Step 1** Set basic parameters.

Figure 7-3 Setting basic parameters



#### **Step 2** Connect to Huawei devices.

- For RS485 communication, click **Search for Device**. The address is automatically allocated.
- For MBUS communication, click Choose File or SN List to add the SN of a device. Click Submit to deliver the added device. Then click Search for Device.

After confirming that the parameters are correct, click **Next**. The dialog box **Do you want to instruct the inverter to start optimizer search?**. Click **OK**.

**Step 3** After the device is connected, set the grid code based on the site requirements.

**Figure 7-4** Setting the grid code



**Step 4** Connect to power meters.

Set related parameters by referring to "**Setting Meter Parameters**" in the *SmartLogger3000 User Manual*.





Figure 7-5 Connecting to power meters

**Step 5** Connect to EMIs.

Figure 7-6 Connecting to EMIs



**Step 6** Connect to a Huawei network management system (NMS).

Set related parameters by referring to "Setting Parameters for Connecting to the Management System" (content related to a Huawei NMS) in the SmartLogger3000 User Manual.

Figure 7-7 Connecting to a Huawei NMS



**Step 7** Connect to a third-party NMS.

Set related parameters by referring to "Setting Parameters for Connecting to the Management System" (content related to a third-party NMS) in the SmartLogger3000 User Manual.


Figure 7-8 Connecting to a third-party NMS



#### **Step 8** Connect to third-party devices.

Set related parameters by referring to "Setting Custom Device Parameters" in the SmartLogger3000 User Manual.

Figure 7-9 Connecting to third-party devices



**Step 9** Click **Finish** to complete the configuration.




Figure 7-10 Completing the configuration

----End

# 7.3.4 Parameters Settings

Choose **Monitoring > Inverter > Running Param.**, set running parameters, and click **Submit**.

Figure 7-11 Setting running parameters



For details about the parameter settings, see the **SmartLogger3000 User Manual**.

# 7.4 Commissioning the SUN5000 (Using the App)

# 7.4.1 Downloading the FusionSolar App

For details, see **Downloading and Installing the App** in the **FusionSolar App User Manual**.

# 7.4.2 Registering an Installer Account

For details, see Registering the Company's First Installer Account in the FusionSolar App User Manual.

# 7.4.3 Deploying a New Plant

For details, see FusionSolar App Quick Guide.

# 8 System Maintenance

#### **DANGER**

 Wear personal protective equipment and use dedicated insulated tools to avoid electric shocks or short circuits.

#### **№ WARNING**

 Before performing maintenance, power off the equipment, follow the instructions on the delayed discharge label, and wait for a period of time as specified to ensure that the equipment is not energized.

# 8.1 Routine Maintenance

To ensure that the inverter can operate properly for a long term, you are advised to perform routine maintenance on it as described in this section.

### **<u>A</u>** CAUTION

- Before cleaning the inverter, connecting cables, and checking the grounding reliability, power off the inverter and ensure that each DC SWITCH on the inverter is set to OFF.
- Do not open the maintenance compartment door on rainy or snowy days. If you need to, take protective measures to prevent rain or snow from entering the maintenance compartment. If protective measures cannot be taken, do not open the maintenance compartment door.

**Table 8-1** Maintenance checklist

Check Item	Check Method	Maintenance Method	Maintenance Interval
Alarm	Check alarms on the app, SmartLogger, or management system.	For details, see 9 Alarm Reference. For details about alarm 2062, see 8.6 Locating Insulation Resistance Faults.	Routine maintenance
Cleanness of air intake and exhaust vents	Periodically check whether there is dust or foreign objects at the air intake and exhaust vents.	Power off the inverter and remove dust and foreign objects. If necessary, remove the baffle plate from the air intake vent for cleaning.	Once every 6 to 12 months (or once every 3 to 6 months based on the actual dust conditions in the environment)
Fan	Check whether the fan generates abnormal noise during operation.	Remove foreign objects from the fan. If the abnormal noise persists, replace the fan. For details, see 8.4 Replacing a Fan.	Once every 6 to 12 months
System running status	<ul> <li>Check whether the inverter is damaged or deformed.</li> <li>Check whether the inverter generates abnormal sounds during operation.</li> <li>Check whether all inverter parameters are correctly set during operation.</li> </ul>	Contact the Company's service engineers.	Once every 6 months

Check Item	Check Method	Maintenance Method	Maintenance Interval
Electrical connection	<ul> <li>Check whether cables are disconnected or loose.</li> <li>Check whether cables are damaged, especially whether the cable sheath that contacts a metal surface is damaged.</li> <li>Check whether the sealing plugs of unused DC input terminals fall off.</li> <li>Check whether the unused COM and USB ports are locked by waterproof caps.</li> </ul>	<ul> <li>Power off the inverter and secure loose or disconnected cables.</li> <li>Power off the inverter and replace the damaged cables.</li> <li>Install sealing plugs on unused DC input terminals.</li> <li>Tighten the waterproof caps on the unused COM and USB ports.</li> </ul>	6 months after the first commissioning and once every 6 to 12 months after that
Groundin g reliability	Check whether the ground cables are securely grounded. Use a multimeter to check whether the ground resistance at the inverter ground screws is less than or equal to $4~\Omega$ .	Tighten the screws on both sides of the ground cable and ensure that the resistance meets the requirements.	6 months after the first commissioning and once every 6 to 12 months after that
Vegetatio n around the inverter	Check whether there are weeds around the inverter.	<ul> <li>Perform         inspection and         weeding as         required.</li> <li>Clean the site         promptly after         weeding.</li> </ul>	Based on the local wilting season

# 8.2 Shutdown and Power-Off

## **⚠** WARNING

After the system is powered off, the inverter is still energized and hot, which may cause electric shocks or burns. Therefore, wait for at least 15 minutes and wear PPE before working on the inverter.

- **Step 1** Send a shutdown command on the app, SmartLogger, or management system. For details, see the user manual of the corresponding product.
- **Step 2** Turn off the AC switch between the inverter and the power grid.
- Step 3 Set the two DC SWITCH to OFF.

----End

### 8.3 Power-Off for Maintenance

#### **Precautions**

To prevent personal injury and device damage, use the DC current scale of a clamp meter to measure the PV string current (even if the DC switches have been turned off) before removing PV connectors when troubleshooting or replacing the inverter or PV strings. Ensure that the PV strings have no current, and quickly remove and insert connectors for adjustment.

#### **!** CAUTION

- If the inverter is faulty, do not stand in front of it if possible.
- If the LED1 indicator on the inverter is off and each DC switch is set to **OFF**, do not operate any DC switch on the inverter. For details, see **Step 4**.
- Do not operate any DC switch on the inverter before you perform Step 3 to Step 5.
- When the inverter detects a fault, it triggers automatic DC disconnection protection. Do not turn on the DC switches before the fault is rectified.
- If the AC switch between the inverter and the power grid has been turned off automatically, do not turn it on before the fault is rectified.
- Before power-off for maintenance, do not touch the energized components of the inverter. Otherwise, electric shocks or arcs may occur.

#### **Procedure**


- **Step 1** Wear proper PPE.
- **Step 2** If the inverter does not shut down due to a fault, send a shutdown command on the app, SmartLogger, or management system. If the inverter has shut down due to a fault, go to the next step.
- **Step 3** Turn off the AC switch between the inverter and the power grid.
- **Step 4** Use a clamp meter to measure the DC current of each PV string input to the inverter.
  - If PV strings have no current, go to the next step.
  - If a PV string has current, wait until the solar irradiance decreases and the PV string has no current at night, and then go to the next step.

- **Step 5** Open the maintenance compartment door, install a support strut, and use a multimeter to check the voltage between the AC terminal block and the ground. Ensure that the AC side of the inverter is powered off.
- **Step 6** Set all DC switches of the inverter to **OFF**. If the DC switches are automatically turned off, go to the next step.
- **Step 7** Wait for 15 minutes and troubleshoot or repair the inverter.

#### **MARNING**

- Do not open the panel for maintenance if the inverter is emitting abnormal smell or smoke, or has obvious exceptions.
- If the inverter does not emit abnormal smell or smoke and is intact, repair or restart it based on the alarm handling suggestions. Do not stand in front of the inverter during the restart.

Figure 8-1 Power-off for maintenance



# 8.4 Replacing a Fan

----End

### **<u>A</u>** CAUTION


- Before replacing a fan, power off the inverter.
- When replacing a fan, use insulated tools and wear PPE.

#### ■ NOTE

If the fan gets stuck when being pulled or pushed, slightly lift it.


**Step 1** Remove the screws from the fan tray and store them properly. Pull out the fan tray until the fan tray is flush with the inverter enclosure.

Figure 8-2 Pulling out the fan tray (1)




**Step 2** Remove the cable ties shared by the cables, unscrew the connectors, and disconnect the cables.

Figure 8-3 Disconnecting cables




**Step 3** Pull out the fan tray.

Figure 8-4 Pulling out the fan tray (2)




- **Step 4** Remove the cable ties from the faulty fan.
  - FAN 1 is faulty.

Figure 8-5 Removing cable ties from FAN 1




FAN 2 is faulty.

Figure 8-6 Removing cable ties from FAN 2




• FAN 3 is faulty.

Figure 8-7 Removing cable ties from FAN 3




**Step 5** Remove the faulty fan (FAN 1 is used as an example).

Figure 8-8 Removing a fan



**Step 6** Install a new fan (FAN 1 is used as an example).


Figure 8-9 Installing a fan



**Step 7** Bind the fan cables.

• Binding positions for FAN 1


Figure 8-10 Binding the cables of FAN 1



IS06H00113


• Binding positions for FAN 2

Figure 8-11 Binding the cables of FAN 2




• Binding positions for FAN 3

Figure 8-12 Binding the cables of FAN 3




**Step 8** Push in the fan tray until the fan baffle plate is flush with the inverter enclosure.

Figure 8-13 Pushing in the fan tray



**Step 9** Connect the cables correctly according to the cable labels and bind the cables.

Figure 8-14 Binding cables



**Step 10** Push in the fan tray completely and tighten the screws.

Figure 8-15 Reinstalling the fan tray

# 8.5 Resetting and Turning On the DC Switch

#### **Prerequisites**

If string backfeed, string connection in reverse polarity, or internal inverter fault is displayed on the mobile app or remote monitoring system and the DC switch is in the **TRIP** position, the DC switch has been automatically turned off. In this case, rectify the fault based on the alarm handling suggestions before turning on the DC switch.

#### **Procedure**

Step 1 Set the DC switch to OFF.

**Step 2** Set the DC switch to **ON**.

----End

----End

# 8.6 Locating Insulation Resistance Faults

If the ground resistance of a PV string connected to the inverter is too low, the inverter generates a **Low insulation resistance** alarm.

The possible causes are as follows:

- A short circuit occurs between the PV array and the ground.
- The ambient air of the PV array is damp and the insulation between the PV array and the ground is poor.

After the **Low insulation resistance** alarm is generated, the inverter automatically triggers insulation resistance fault location. If the fault location is successful, the location information is displayed on the **Alarm Details** screen of the **Low insulation resistance** alarm on the FusionSolar app.

Log in to the FusionSolar app, choose **Alarm** > **Active alarm**, and choose **Low insulation resistance** to enter the **Alarm Details** screen.

#### □ NOTE

- The positive and negative terminals of a PV string are connected to the PV+ and PVterminals of the inverter, respectively. The 0% position corresponds to the PV- terminal, and the 100% position corresponds to the PV+ terminal. Other percentages indicate that the fault occurs on a PV module or cable in the PV string.
- Possible fault position = Total number of PV modules in a PV string x Percentage of possible short-circuit positions. For example, if a PV string consists of 14 PV modules and the percentage of the possible short-circuit position is 34%, the possible fault position is 4.76 (14 x 34%), indicating that the fault is located near PV module 4, including the adjacent PV modules and their cables. The inverter has a detection precision of ±1 PV module.
- For details about the PV strings corresponding to the MPPT that may be faulty, see
   Table 8-2. The fault can be located only to the MPPT level. Perform the following steps
   to connect the PV strings corresponding to the faulty MPPT to the inverter one by one
   to further locate and rectify the fault.
- When a non-short-circuit fault occurs, the possible short-circuit percentage is not displayed. If the insulation resistance is greater than 0.001 M $\Omega$ , the fault is not related to short circuit. Check all PV modules in the faulty PV string one by one to locate and rectify the fault.

Figure 8-16 Definition of the percentage of the short-circuit position




Table 8-2 Mapping between MPPTs and PV strings

MPPTn	PV String	MPPTn	PV String
MPPT1	PV1 to PV3	MPPT2	PV4 to PV6
МРРТ3	PV7 to PV9	MPPT4	PV10 to PV12
MPPT5	PV13 to PV15	МРРТ6	PV16 to PV18
МРРТ7	PV19 to PV21	-	-

#### Procedure

#### NOTICE

- In SUN2000MG V600R023C10SPC101 and later versions, insulation resistance detection upon shutdown is supported. If the AC side is not powered on, insulation resistance fault locating is not supported.
- If the irradiance is too strong, the PV string voltage is too high, or only the DC side is powered on but the AC side is not powered on, the insulation resistance fault locating may fail. In this case, the fault locating status on the Alarm Details screen is Conditions not met. Check the PV string voltage on the app, SmartLogger, or the management system. If the voltage is within the normal range, perform the following steps to connect PV strings to the inverter one by one to locate the fault.
- **Step 1** Ensure that the AC connections are normal. Log in to the FusionSolar app, choose **Maintenance** > **Inverter ON/OFF** on the home screen, and send a shutdown command. Set the **DC SWITCH** of the inverter to **OFF**.
- **Step 2** Connect a PV string to the inverter and set the **DC SWITCH** to **ON**. If the inverter status is **Shutdown: Command**, choose **Maintenance** > **Inverter ON/OFF** on the home screen and send a startup command.
- **Step 3** Choose **Alarm** on the home screen, enter the **Active alarm** screen, and check whether a **Low insulation resistance** alarm is reported.
  - If no Low insulation resistance alarm is reported 1 minute after the DC side is powered on, choose Maintenance > Inverter ON/OFF on the home screen and send a shutdown command. Set the DC SWITCH to OFF. Go to Step 2 and check the other PV strings one by one.
  - If a **Low insulation resistance** alarm is reported 1 minute after the DC side is powered on, check the percentage of possible short-circuit positions on the **Alarm Details** screen and calculate the location of the possibly faulty PV module based on the percentage. Then go to **Step 4**.
- **Step 4** Choose **Maintenance** > **Inverter ON/OFF** on the home screen and send a shutdown command. Set the **DC SWITCH** to **OFF**. Check whether the connectors or DC power cables between the possibly faulty PV modules and adjacent PV modules are damaged.
  - If yes, replace the damaged connectors or DC power cables and then set the DC SWITCH to ON. If the inverter status is Shutdown: Command, choose Maintenance > Inverter ON/OFF on the home screen and send a startup command. View alarm information.
    - If no Low insulation resistance alarm is reported 1 minute after the DC side is powered on, the insulation resistance fault location of the PV string is complete. Choose Maintenance > Inverter ON/OFF on the home screen and send a shutdown command. Set the DC SWITCH to OFF. Go to Step 2 and check the other PV strings one by one. Then, go to Step 7.
    - If the Low insulation resistance alarm is still reported 1 minute after the DC side is powered on, choose Maintenance > Inverter ON/OFF on the

home screen and send a shutdown command. Set the **DC SWITCH** to **OFF** and go to **Step 5**.

- If no, go to **Step 5**.
- Step 5 Disconnect the possibly faulty PV module from the PV string, and use a DC extension cable with MC4 connectors to connect the adjacent PV modules. set the DC SWITCH to ON. If the inverter status is Shutdown: Command, choose Maintenance > Inverter ON/OFF on the home screen and send a startup command. View alarm information.
  - If no Low insulation resistance alarm is reported 1 minute after the DC side is powered on, the fault occurred on the disconnected PV module. Choose Maintenance > Inverter ON/OFF on the home screen, send a shutdown command, and set the DC SWITCH to OFF. Go to Step 7.
  - If the **Low insulation resistance** alarm is still reported 1 minute after the DC side is powered on, the fault did not occur on the disconnected PV module. Go to **Step 6**.
- Step 6 Choose Maintenance > Inverter ON/OFF on the home screen and send a shutdown command. Set the DC SWITCH to OFF, reconnect the disconnected PV module, and repeat Step 5 to check the adjacent PV modules at the possible fault position.
- **Step 7** Set the **DC SWITCH** to **ON**. If the inverter status is **Shutdown: Command**, choose **Maintenance** > **Inverter ON/OFF** on the home screen and send a startup command.

----End

# 9 Alarm Reference

For details about alarms, see Inverter Alarm Reference.

# 10 Technical Specifications

### **Efficiency**

Item	SUN5000-150K-MG0-ZH	SUN5000-150K-MG0
Maximum efficiency	≥ 98.6% (380 V), ≥ 98.8% (480 V)	≥ 98.6% (380 V/400 V), ≥ 98.8% (480 V)
Chinese efficiency	≥ 98.2% (380 V), ≥ 98.4% (480 V)	1
Efficiency in Europe	1	≥ 98.3% (380 V), ≥ 98.4% (400 V), ≥ 98.6% (480 V)

#### Input

Item	SUN5000-150K-MG0-ZH	SUN5000-150K-MG0
Maximum input voltage <sup>a</sup>	1100 V	1100 V
Operating voltage range <sup>b</sup>	200–1000 V	200–1000 V
Minimum startup voltage	200 V	200 V
Full-load MPPT voltage range <sup>c</sup>	540-800 V (380 V) 625-850 V (480 V)	540-800 V (380 V/400 V) 625-850 V (480 V)
Rated input voltage	600 V (380 V), 720 V (480 V)	600 V (380 V/400 V), 720 V (480 V)
Maximum input current (per MPPT)	48 A	48 A
Maximum input current (per PV string)	23 A	23 A

Item	SUN5000-150K-MG0-ZH	SUN5000-150K-MG0
Maximum short- circuit current (per MPPT)	66 A	66 A
Number of inputs	21	21
Number of MPPT circuits	7	7

Note a: The maximum input voltage is the maximum DC input voltage that the inverter can withstand. If the input voltage exceeds this value, the inverter may be damaged.

Note b: If the input voltage is beyond the operating voltage range, the inverter cannot work properly.

Note c: The PV strings connecting to the same MPPT circuit shall use the same model and quantity of PV modules. It is recommended that the PV string voltage be higher than the lower threshold of the full-load MPPT voltage.

#### **Output**

Item	SUN5000-150K-MG0-ZH	SUN5000-150K-MG0
Rated output power	150 kW	150 kW
Maximum apparent power	165 kVA	165 kVA
Maximum active power (cosφ = 1)	165 kW	165 kW
Rated output voltage <sup>a</sup>	Phase voltage/Line voltage: 220/380 V, 277/480 V	Phase voltage/Line voltage: 220 V/380 V, 230 V/400 V, 277 V/480 V
	3W + (N) <sup>b</sup> + PE	3W + (N) <sup>b</sup> + PE
Rated output current	227.9 A (380 V)	227.9 A (380 V)
	180.4 A (480 V)	216.5 A (400 V)
		180.4 A (480 V)
Adapted power grid frequency	50 Hz/60 Hz	50 Hz/60 Hz
Maximum output	253.2 A (380 V)	253.2 A (380 V)
current	200.5 A (480 V)	240.5 A (400 V)
		200.5 A (480 V)
Power factor	0.8 leading to 0.8 lagging	0.8 leading to 0.8 lagging
Maximum total harmonic distortion (rated power)	< 1% (rated working conditions)	< 1% (rated working conditions)

Item	SUN5000-150K-MG0-ZH	SUN5000-150K-MG0
Output DC component (DCI)	< 0.5% of the rated current	< 0.5% of the rated current

Note a: The rated output voltage is determined by **Grid code**, and **Grid code** can be set on the SUN2000 app, SmartLogger, or management system.

Note b: You can determine whether to connect the N wire to the SUN5000 based on the application scenario. In scenarios without N wires, set **Output mode** to **Three-phase**, **three-wire**. In scenarios with N wires, set **Output mode** to **Three-phase**, **four-wire**.

#### **Protection**

Item	SUN5000-150K-MG0-ZH	SUN5000-150K-MG0	
Arc-fault circuit interrupter (AFCI)			
Built-in PID recovery	Supported	Supported	
Input DC switch	Supported	Supported	
Anti-islanding protection			
Output overcurrent protection	Supported	Supported	
Input reverse connection protection	Supported	Supported	
PV string fault detection	Supported	Supported	
DC surge protection	Supported	Supported	
AC surge protection	Supported	Supported	
Insulation resistance detection	Supported	Supported	
Residual current monitoring unit (RCMU)	Supported	Supported	
Overvoltage category	PV II/AC III	PV II/AC III	

# **Display and Communication**

Item	SUN5000-150K-MG0-ZH	SUN5000-150K-MG0
Display	LED indicator; WLAN module + app; USB data cable + app	

Item	SUN5000-150K-MG0-ZH	SUN5000-150K-MG0
RS485	Supported	
AC MBUS	Supported	
Optimizer	Supported	

# **General Specifications**

Item	SUN5000-150K-MG0-ZH	SUN5000-150K-MG0
Dimensions (W x H x D)	1000 mm x 710 mm x 395 mm	1000 mm x 710 mm x 395 mm
Net weight (including hanging kits)	102 kg	102 kg
Operating temperature	-25°C to +60°C	−25°C to +60°C
Cooling mode	Smart air cooling	Smart air cooling
Operating altitude	0-5000 m (derated when the altitude exceeds 4000 m)	0-5000 m (derated when the altitude exceeds 4000 m)
Relative humidity	0%-100% RH	0%-100% RH
Input and output terminals	DC input terminals: CT75A-1T-34/ CT75A-1T-35CT75A-1T-34/ CT75A-1T-35 (AVIC JONHON)	DC input terminal: HH4SFD4TMS/ HH4SMD4TMS (Amphenol)
	AC output terminals: waterproof terminal + OT/DT terminal	AC output terminals: waterproof terminal + OT/DT terminal
IP rating	IP66	IP66
Topology	Transformerless	Transformerless

# A Grid Codes

No.	Grid Code	Description (Country/ Region/ Standard/ Others)	SUN5000-150K -MG0-ZH	SUN5000-150K -MG0
1	NB/T 32004	China low- voltage power grid	Supported	Supported
2	Custom (50Hz)	Reserved	Supported	Supported
3	Custom (60Hz)	Reserved	Supported	Supported
4	CHINA-MV480	China medium- voltage standard power grid	Supported	-
5	CHINA-MV	China medium- voltage standard power grid	Supported	Supported
6	Fuel-Engine- Grid	Genset hybrid power grid	Supported	Supported
7	Fuel-Engine- Grid-60Hz	Genset hybrid power grid	Supported	Supported
8	VDE-AR-N-4105	Germany low- voltage power grid	-	Supported
9	UTE C 15-712-1(A)	France mainland power grid	-	Supported

No.	Grid Code	Description (Country/ Region/ Standard/ Others)	SUN5000-150K -MG0-ZH	SUN5000-150K -MG0
10	UTE C 15-712-1(B)	France island power grid	-	Supported
11	UTE C 15-712-1(C)	France island power grid	-	Supported
12	VDE 0126-1-1- BU	Bulgaria power grid	-	Supported
13	VDE 0126-1-1- GR(A)	Greece mainland power grid	-	Supported
14	VDE 0126-1-1- GR(B)	Greece island power grid	-	Supported
15	BDEW-MV	Germany medium- voltage power grid	-	Supported
16	G59-England	England 230 V power grid (I > 16 A)	-	Supported
17	G59-Scotland	Scotland 240 V power grid (I > 16 A)	-	Supported
18	G83-England	England 230 V power grid (I < 16 A)	-	Supported
19	G83-Scotland	Scotland 240 V power grid (I < 16 A)	-	Supported
20	CEI0-21	Italy power grid	-	Supported
21	EN50438-CZ	Czech Republic power grid	-	Supported
22	RD1699/661	Spain low- voltage power grid	-	Supported
23	RD1699/661- MV480	Spain medium- voltage power grid	-	Supported

No.	Grid Code	Description (Country/ Region/ Standard/ Others)	SUN5000-150K -MG0-ZH	SUN5000-150K -MG0
24	EN50438-NL	Netherlands power grid	-	Supported
25	C10/11	Belgium power grid	-	Supported
26	AS4777	Australia power grid	-	Supported
27	IEC61727	IEC 61727 low- voltage grid- connection (50 Hz)	-	Supported
28	CEI0-16	Italy power grid	-	Supported
29	TAI-PEA	Thailand grid- connection standard	-	Supported
30	TAI-MEA	Thailand grid- connection standard	-	Supported
31	BDEW-MV480	Germany medium- voltage standard power grid	-	Supported
32	Custom- MV480(50Hz)	Reserved	-	Supported
33	Custom- MV480(60Hz)	Reserved	-	Supported
34	G59-England- MV480	UK 480 V medium- voltage grid connection (I > 16 A)	-	Supported
35	IEC61727- MV480	IEC 61727 medium- voltage grid- connection (50 Hz)	-	Supported

No.	Grid Code	Description (Country/ Region/ Standard/ Others)	SUN5000-150K -MG0-ZH	SUN5000-150K -MG0
36	UTE C 15-712-1- MV480	France island power grid	-	Supported
37	TAI-PEA-MV480	Thailand medium- voltage grid- connection (PEA)	-	Supported
38	TAI-MEA- MV480	Thailand medium- voltage grid- connection (MEA)	-	Supported
39	EN50438-DK- MV480	Denmark medium- voltage grid- connection	-	Supported
40	EN50438-TR- MV480	Türkiye medium- voltage power grid	-	Supported
41	EN50438-TR	Türkiye low- voltage power grid	-	Supported
42	C11/C10-MV480	Belgium medium- voltage power grid	-	Supported
43	Philippines	Philippines low- voltage power grid	-	Supported
44	Philippines- MV480	Philippines medium- voltage power grid	-	Supported
45	AS4777-MV480	Australia medium- voltage power grid	-	Supported

No.	Grid Code	Description (Country/ Region/ Standard/ Others)	SUN5000-150K -MG0-ZH	SUN5000-150K -MG0
46	NRS-097-2-1	South Africa standard power grid	-	Supported
47	NRS-097-2-1- MV480	South Africa medium- voltage standard power grid	-	Supported
48	KOREA	South Korea power grid	-	Supported
49	IEC61727-60Hz	IEC 61727 low- voltage grid- connection (60 Hz)	-	Supported
50	IEC61727-60Hz- MV480	IEC 61727 medium- voltage grid- connection (60 Hz)	-	Supported
51	ANRE	Romania low- voltage power grid	-	Supported
52	ANRE-MV480	Romania medium- voltage power grid	-	Supported
53	PO12.3-MV480	Spain medium- voltage power grid	-	Supported
54	EN50438_IE- MV480	Ireland medium- voltage power grid	-	Supported
55	EN50438_IE	Ireland low- voltage power grid	-	Supported
56	CEI0-16-MV480	Italy medium- voltage power grid	-	Supported

No.	Grid Code	Description (Country/ Region/ Standard/ Others)	SUN5000-150K -MG0-ZH	SUN5000-150K -MG0
57	PO12.3	Spain low- voltage power grid	-	Supported
58	CEI0-21-MV480	Italy medium- voltage power grid	-	Supported
59	KOREA-MV480	South Korea medium- voltage power grid	-	Supported
60	Egypt ETEC	Egypt low- voltage power grid	-	Supported
61	Egypt ETEC- MV480	Egypt medium- voltage power grid	-	Supported
62	EN50549-LV	Ireland power grid	-	Supported
63	EN50549- MV480	Ireland medium- voltage power grid	-	Supported
64	Jordan- Transmission	Jordan low- voltage power grid	-	Supported
65	Jordan- Transmission- MV480	Jordan medium- voltage power grid	-	Supported
66	NAMIBIA	Namibia power grid	-	Supported
67	ABNT NBR 16149	Brazil power grid	-	Supported
68	ABNT NBR 16149-MV480	Brazil medium- voltage power grid	-	Supported
69	SA_RPPs	South Africa low-voltage power grid	-	Supported

No.	Grid Code	Description (Country/ Region/ Standard/ Others)	SUN5000-150K -MG0-ZH	SUN5000-150K -MG0
70	SA_RPPs-MV480	South Africa medium- voltage power grid	-	Supported
71	ZAMBIA	Zambia low- voltage power grid	-	Supported
72	ZAMBIA-MV480	Zambia medium- voltage power grid	-	Supported
73	Chile	Chile low- voltage power grid	-	Supported
74	Chile-MV480	Chile medium- voltage power grid	-	Supported
75	Mexico-MV480	Mexico medium- voltage power grid	-	Supported
76	Malaysian	Malaysia low- voltage power grid	-	Supported
77	Malaysian- MV480	Malaysia medium- voltage power grid	-	Supported
78	KENYA_ETHIOPI A	Kenya low- voltage power grid and Ethiopia power grid	-	Supported
79	KENYA_ETHIOPI A-MV480	Kenya low- voltage power grid and Ethiopia medium- voltage power grid	-	Supported

No.	Grid Code	Description (Country/ Region/ Standard/ Others)	SUN5000-150K -MG0-ZH	SUN5000-150K -MG0
80	NIGERIA	Nigeria low- voltage power grid	-	Supported
81	NIGERIA-MV480	Nigeria medium- voltage power grid	-	Supported
82	DUBAI	Dubai low- voltage power grid	-	Supported
83	DUBAI-MV480	Dubai medium- voltage power grid	-	Supported
84	Northern Ireland	Northern Ireland low- voltage power grid	-	Supported
85	Northern Ireland-MV480	Northern Ireland medium- voltage power grid	-	Supported
86	Cameroon	Cameroon low- voltage power grid	-	Supported
87	Cameroon- MV480	Cameroon medium- voltage power grid	-	Supported
88	Jordan- Distribution	Jordan power distribution network low- voltage power grid	-	Supported
89	Jordan- Distribution- MV480	Jordan power distribution network medium- voltage power grid	-	Supported

No.	Grid Code	Description (Country/ Region/ Standard/ Others)	SUN5000-150K -MG0-ZH	SUN5000-150K -MG0
90	NAMIBIA_MV48 0	Namibia power grid	-	Supported
91	LEBANON	Lebanon low- voltage power grid	-	Supported
92	LEBANON- MV480	Lebanon medium- voltage power grid	-	Supported
93	ARGENTINA- MV500	Argentina medium- voltage power grid	-	Supported
94	Jordan- Transmission- HV	Jordan high- voltage power grid	-	Supported
95	Jordan- Transmission- HV480	Jordan high- voltage power grid	-	Supported
96	TUNISIA	Tunisia power grid	-	Supported
97	TUNISIA-MV480	Tunisia medium- voltage power grid	-	Supported
98	AUSTRALIA- NER	Australia NER standard power grid	-	Supported
99	AUSTRALIA- NER-MV480	Australia NER standard power grid	-	Supported
100	SAUDI	Saudi Arabia power grid	-	Supported
101	SAUDI-MV480	Saudi Arabia power grid	-	Supported
102	Ghana-MV480	Ghana medium- voltage power grid	-	Supported

No.	Grid Code	Description (Country/ Region/ Standard/ Others)	SUN5000-150K -MG0-ZH	SUN5000-150K -MG0
103	Israel	Israel power grid	-	Supported
104	Israel-MV480	Israel power grid	-	Supported
105	Chile-PMGD	Chile PMGD power grid	-	Supported
106	Chile-PMGD- MV480	Chile PMGD power grid	-	Supported
107	VDE-AR-N4120- HV	VDE 4120 standard power grid	-	Supported
108	VDE-AR-N4120- HV480	VDE 4120 standard power grid	-	Supported
109	Vietnam	Vietnam power grid	-	Supported
110	Vietnam-MV480	Vietnam power grid	-	Supported
111	TAIPOWER	Taiwan Power low-voltage power grid	-	Supported
112	TAIPOWER- MV480	Taiwan Power medium- voltage power grid (480 V)	-	Supported
113	ARGENTINA- MV480	Argentina medium- voltage power grid	-	Supported
114	OMAN	Oman low- voltage power grid	-	Supported
115	OMAN-MV480	Oman medium- voltage power grid	-	Supported

No.	Grid Code	Description (Country/ Region/ Standard/ Others)	SUN5000-150K -MG0-ZH	SUN5000-150K -MG0
116	KUWAIT	Kuwait low- voltage power grid	-	Supported
117	KUWAIT-MV480	Kuwait medium- voltage power grid	-	Supported
118	BANGLADESH	Bangladesh low-voltage power grid	-	Supported
119	BANGLADESH- MV480	Bangladesh medium- voltage power grid	-	Supported
120	Chile- Net_Billing	Chile Net Billing power grid	-	Supported
121	EN50438-NL- MV480	Netherlands medium- voltage power grid	-	Supported
122	BAHRAIN	Bahrain low- voltage power grid	-	Supported
123	BAHRAIN- MV480	Bahrain medium- voltage power grid	-	Supported
124	ARGENTINA	Argentina power grid	-	Supported
125	Mauritius	Mauritius power grid	-	Supported
126	Mauritius- MV480	Mauritius medium- voltage power grid	-	Supported
127	EN50438-SE	Sweden low- voltage power grid	-	Supported

No.	Grid Code	Description (Country/ Region/ Standard/ Others)	SUN5000-150K -MG0-ZH	SUN5000-150K -MG0
128	Pakistan	Pakistan power grid	-	Supported
129	Pakistan-MV480	Pakistan medium- voltage power grid	-	Supported
130	Austria	Austria power grid	-	Supported
131	Austria-MV480	Austria medium- voltage power grid	-	Supported
132	G99-TYPEA-LV	UK G99-TYPEA- LV power grid	-	Supported
133	G99-TYPEB-LV	UK G99-TYPEB- LV power grid	-	Supported
134	G99-TYPEB-HV	UK G99-TYPEB- HV power grid	-	Supported
135	G99-TYPEB-HV- MV480	UK G99-TYPEB- HV medium- voltage power grid	-	Supported
136	G99-TYPEA-HV	UK G99-TYPEA- HV power grid	-	Supported
137	EN50549- MV400	Ireland new standard power grid	-	Supported
138	VDE-AR-N4110	Germany medium- voltage power grid (230 V)	-	Supported
139	VDE-AR-N4110- MV480	Germany medium- voltage standard power grid	-	Supported
140	NTS	Spain power grid	-	Supported

No.	Grid Code	Description (Country/ Region/ Standard/ Others)	SUN5000-150K -MG0-ZH	SUN5000-150K -MG0
141	NTS-MV480	Spain medium- voltage power grid	-	Supported
142	SINGAPORE	Singapore low- voltage power grid	-	Supported
143	SINGAPORE- MV480	Singapore medium- voltage power grid	-	Supported
144	HONGKONG	Hong Kong low- voltage power grid	-	Supported
145	HONGKONG- MV480	Hong Kong medium- voltage power grid	-	Supported
146	C10/11-MV400	Belgium medium- voltage power grid	-	Supported
147	Cambodia	Cambodia power grid	-	Supported
148	Cambodia- MV480	Cambodia medium- voltage power grid	-	Supported
149	EN50549-SE	Sweden low- voltage power grid	-	Supported
150	GREG030	Colombia low- voltage power grid	-	Supported
151	GREG030- MV440	Colombia medium- voltage power grid	-	Supported

No.	Grid Code	Description (Country/ Region/ Standard/ Others)	SUN5000-150K -MG0-ZH	SUN5000-150K -MG0
152	GREG030- MV480	Colombia medium- voltage power grid	-	Supported
153	PORTUGAL	Portugal low- voltage power grid	-	Supported
154	PORTUGAL- MV480	Portugal medium- voltage power grid	-	Supported
155	AS4777_ACT	Australia power grid	-	Supported
156	AS4777_NSW_E SS	Australia power grid	-	Supported
157	AS4777_NSW_A G	Australia power grid	-	Supported
158	AS4777_QLD	Australia power grid	-	Supported
159	AS4777_SA	Australia power grid	-	Supported
160	AS4777_VIC	Australia power grid	-	Supported
161	EN50549-PL	Poland power grid	-	Supported
162	DANMARK- EN50549-DK1- LV230	Denmark power grid	-	Supported
163	DANMARK- EN50549-DK2- LV230	Denmark power grid	-	Supported
164	AUSTRALIA- AS4777_A- LV230	Australia power grid	-	Supported
165	AUSTRALIA- AS4777_B- LV230	Australia power grid	-	Supported

No.	Grid Code	Description (Country/ Region/ Standard/ Others)	SUN5000-150K -MG0-ZH	SUN5000-150K -MG0
166	AUSTRALIA- AS4777_C- LV230	Australia power grid	-	Supported
167	AUSTRALIA- AS4777_NZ- LV230	Australia power grid	-	Supported
168	INVALID GRID CODE	Invalid grid code	-	Supported
169	CZECH- EN50549-LV230	Czech Republic power grid	-	Supported
170	CZECH- EN50549- MV480	Czech Republic power grid	-	Supported
171	ISRAEL-MV400	Israel medium- voltage 400 V power grid	-	Supported
172	ANRE-TYPEB	Romania power grid (type B)	-	Supported
173	ANRE-TYPEB- MV480	Romania power grid (type B)	-	Supported
174	AUSTRIA- TYPEB-LV400	Austria power grid	-	Supported
175	AUSTRIA- TYPEB-LV480	Austria power grid	-	Supported
176	AUSTRIA- TYPEB-MV400	Austria power grid	-	Supported
177	AUSTRIA- TYPEB-MV480	Austria power grid	-	Supported

### □ NOTE

The grid codes are subject to change. The listed codes are for reference only.

### B Rapid Shutdown

If optimizers are configured for all PV modules, the PV system can perform a rapid shutdown to decrease the output voltage to below 30 V within 30s.

Perform the following steps to trigger a rapid shutdown:

- Method 1 (recommended): Turn off the AC switch between the inverter and the power grid.
- Method 2: Turn off the two DC switches at the bottom of the inverter.
- Method 3: If AFCI is enabled, the inverter automatically performs arc fault detection and triggers a rapid shutdown when AFCI lock protection is implemented.

## C Resetting a Password

- **Step 1** Check that the AC and DC sides of the inverter are both powered on, and indicators and → are steady green or blinking slowly for more than 3 minutes.
- **Step 2** Turn off the AC switch, set the DC SWITCH at the bottom of the inverter to OFF, and wait until all LED indicators on the inverter panel turn off.
- **Step 3** After the inverter is powered off, complete the following operations within 4 minutes:
  - 1. Turn on the AC switch and wait for about 90s or until the inverter indicator > blinks.
  - 2. Turn off the AC switch and wait about 30s or until all LED indicators on the inverter panel turn off.
  - 3. Turn on the AC switch and wait for about 90s or until the inverter indicator > blinks.
- **Step 4** Log in to the app and reset the password within 10 minutes. (If no operation is performed within 10 minutes, all parameters of the inverter remain unchanged.)

----End

### **NOTICE**

You are advised to reset the password in the morning or at night when the solar irradiance is low.

### Crimping an OT or DT Terminal

### Requirements for the OT or DT Terminal

- If a copper cable is used, use copper wiring terminals.
- If a copper-clad aluminum cable is used, use copper wiring terminals.
- If an aluminum alloy cable is used, use copper-aluminum transition wiring terminals, or aluminum wiring terminals along with copper-aluminum transition spacers.

### NOTICE

- Do not connect aluminum wiring terminals to the AC terminal block. Otherwise the electrochemical corrosion will occur and affect the reliability of cable connections.
- Comply with the IEC61238-1 requirements when using copper-aluminum transition wiring terminals, or aluminum wiring terminals along with copper-aluminum transition spacers.
- If copper-aluminum transition spacers are used, pay attention to the front and rear sides. Ensure that the aluminum sides of spacers are in contact with aluminum wiring terminals, and copper sides of spacers are in contact with the AC terminal block.




Figure D-1 Requirements for the OT/DT terminal

IS03H00062

### Crimping an OT or DT Terminal

### **NOTICE**

- Pay attention not to scratch the core wire when stripping a cable.
- The cavity formed after the conductor crimp strip of the OT or DT terminal is crimped must wrap the core wires completely. The core wires must contact the OT or DT terminal closely.
- Wrap the wire crimping area with a heat shrink tubing or PVC insulation tape. The heat shrink tubing is used as an example.
- When using a heat gun, protect devices from being scorched.





Figure D-2 Crimping an OT terminal

- (1) Cable
- (4) OT terminal
- (2) Core
- (5) Hydraulic pliers
- (3) Heat shrink tubing
- (6) Heat gun

Figure D-3 Crimping a DT terminal



- (4) DT terminal
- (5) Hydraulic pliers
- (3) Heat shrink tubing
- (6) Heat gun

## Baud Rate Negotiation

Baud rate negotiation improves the communications rate between the inverter and Dongle, solving or relieving communication congestion.

- During device search in a new plant, the system automatically negotiates the baud rate.
- When replacing or adding an inverter or Smart Dongle at an existing plant, you need to manually deliver local commands on the FusionSolar app to reset the baud rate between devices and negotiate a higher rate.

### NOTICE

Baud rate negotiation applies only to RS485 communication in which Dongle networking is used. The inverters networked must be the MG0 series.

**Table E-1** Manual baud rate negotiation on the app

Networkin g Mode	Scenario	Operation
Smart Dongle networking	Replacing the Smart Dongle	Use the FusionSolar app to locally scan the QR code to connect to the Dongle.
		<ol> <li>Access the Communication configuration screen, choose RS485</li> <li>Baud Rate Negotiation, and tap 9600 and Negotiate a higher rate.</li> </ol>
	Replacing or adding an inverter	Use the FusionSolar app to locally scan the QR code to connect to the Dongle.
		<ol> <li>Access the Communication configuration screen, choose RS485</li> <li>Baud Rate Negotiation, and tap 9600 and Negotiate a higher rate.</li> </ol>

### **Troubleshooting**

If manual baud rate negotiation fails, refer to the following troubleshooting measures.

**Table E-2** Troubleshooting measures

Scenario	Troubleshooting
Negotiat ion failed	Check whether the device cables are connected properly. If no, connect the device cables correctly.
	2. Check whether service operations such as upgrade and log export are performed on the management system. If yes, perform baud rate negotiation again after such operations are complete.
	3. Perform baud rate negotiation again.
	4. When you replace or add an inverter, if you tap <b>Negotiate a higher rate</b> and a message "Negotiation failed. The southbound device does not support the rate." is displayed, it indicates that the device connected to the Dongle does not support baud rate negotiation. In this case, you only need to tap <b>9600</b> .
	5. If the fault persists, contact your vendor.

### Contact Information

If you have any questions about this product, please contact us.



https://digitalpower.huawei.com

Path: About Us > Contact Us > Service Hotlines

To ensure faster and better services, we kindly request your assistance in providing the following information:

- Model
- Serial number (SN)
- Software version
- Alarm ID or name
- Brief description of the fault symptom

### □ NOTE

EU Representative Information: Huawei Technologies Hungary Kft. Add.: HU-1133 Budapest, Váci út 116-118., 1. Building, 6. floor.

Email: hungary.reception@huawei.com

## G Digital Power Customer Service



https://digitalpower.huawei.com/robotchat/

# Acronyms and Abbreviations

Α

AFCI arc-fault circuit

interrupter

L

**LED** light emitting diode

Μ

MBUS monitoring bus

MPP maximum power point

MPPT maximum power point

tracking

Ρ

PID potential induced

degradation

**PV** photovoltaic

R

**RCMU** 

residual current monitoring unit